


Spare parts

PRICES VALID FROM: 1. JANUARY 2025



Code	Description	Gross Price without VAT
JP41200	SPARE CONNECTION SET DN 50	13,20
JP42770	SPARE SWITCH SHAFT 1	21,90
JP42771	SPARE FLOAT 1	19,70
JP42772	SPARE COVER U6	29,80
JP42773	SPARE SCREW SET 1	23,10
JP42774	SPARE SEAL KIT U6K	37,00
JP42776	SPARE CABLE 12-4M	91,00
JP42777	SPARE CABLE 12-10M	125,00
JP42778	SPARE CABLE 13-4M	125,00
JP42779	SPARE CABLE 13-10M	158,00
JP42792	SPARE ELASTIC CONNECTION SET DN 80	96,00
JP42793	SPARE FLANGE SET DN 80 COMPLETE	118,00
JP42794	SPARE REFLUX VALVE COMPLI 300 COMPL.	191,00
JP42795	SPARE CLAMPING FLANGE DN100	36,00
JP42796	SPARE BUOYANCY PROTECTION COMPLI 300	54,00
JP42797	SPARE BASE PLATE COMPLETE	507,00
JP42798	SPARE SERVICE LID WITH SEAL	38,00
JP42799	SPARE PUMP VENTILATION COMPLI 300	28,40
JP42800	SPARE SET OF SCREWS COMPLI 300	157,00
JP42801	SPARE SET OF SEALS COMPLI 300	158,00
JP42802	SPARE PLUG-IN CONTROL UNIT COMPLI 300	350,00
JP42806	SPARE BEARING HOUSING SET COMPLI 300	207,00
JP42807	SPARE VORTEX IMPELLER MIT BEFESTIGUNG	67,00
JP42808	SPARE LEVEL CONTR. UNIT COMPLI 300	236,00
JP42809	SPARE SET OF SCREWS UC 300	27,10
JP42810	SPARE SEAL KIT UC 300	44,00
JP43705	SPARE ELASTIC CONNECTION SET DN 100	96,00
JP43706	SPARE CONNECTION FLANGE B100 COMPL.	97,00
JP43707	SPARE REFLUX VALVE R80 COMPLI	378,00
JP43708	SPARE REVOLVER CLAMPING FLANGE DN 100	112,00
JP43709	SPARE BUOYANCY PROTECTION COMPLI	54,00
JP43710	SPARE PUMP VENTILATION COMPLI	22,50
JP43711	SPARE BASE PLATE COMPLI 400/500	558,00
JP43712	SPARE LEVEL CONTROLLER COMPLI	206,00
JP43713	SPARE CLAMPING FLANGE SET DN 150	60,00
JP43714	SPARE BASE PLATE COMPLI 1000/1200	1069,00
JP43715	SPARE BLIND FLANGE SET COMPLI 600	248,00
JP43716	SPARE BUOYANCY PROTEC. COMPLI 1200/1500	142,00
JP43717	SPARE CABLE UC 4M	201,00
JP43718	SPARE UC 9/4 BW 1+2 STATOR	837,00
JP43719	SPARE UC 4-POLE BW	93,00
JP43720	SPARE BEARING HOUSING UC /4 BW	204,00
JP43721	SPARE CABLE UC 10/4 BWE	225,00
JP43722	SPARE UC 10/4 BWE STATOR	891,00
JP43723	SPARE UC 10/4 - 25/4 BW STATOR	891,00
JP43724	SPARE UC 25/2 BW STATOR	891,00
JP43725	SPARE UC 35/2 BW STATOR	891,00
JP43726	SPARE BEARING HOUSING UC /2 BW	578,00
JP43727	SPARE BEARING+SEALS SET UC 2-POLE BW	200,00
JP43728	SPARE VORTEX IMPELLER UC 25/2 BW	192,00
JP43729	SPARE VORTEX IMPELLER UC 35/2 BW	192,00

JP43730	SPARE SET OF SEALS UC 2-POLE BW	29,80
JP43731	SPARE ELASTIC CONNECTION SET DN 50	84,00
JP43732	SPARE PUMP VENTILATION SET COMPLI M	62,00
JP43733	SPARE BUOYANCY PROTECTION COMPLI 100	39,00
JP43734	SPARE LEVEL CONTR. UNIT COMPLI 100	206,00
JP43735	SPARE ELASTIC CONNECTION SET DN 40	84,00
JP43736	SPARE UC 08/2 M STATOR	724,00
JP43737	SPARE UC 08/2 M STATOR	738,00
JP43738	SPARE UC 20/2 M STATOR	769,00
JP43739	SPARE BEARING HOUSING UC 08+25	288,00
JP43740	SPARE BASE PLATE COMPLI 500+1000 M	558,00
JP44006	SPARE STATOR SET UC 08/2 M C.100	811,00
JP44007	SPARE STATOR SET UC 08/2 M C.100	811,00
JP44008	SPARE STATOR SET D90-2/75	826,00
JP44011	SPARE BEARING HOUSING UC25/2 M C.100	251,00
JP44012	SPARE VOLUTE CASING UC 25/2M C.100	384,00
JP44013	SPARE BASE PLATE REPAIR SET C.125/2M	250,00
JP44014	SPARE VOLUTE CASING UC 08/2M+ME C.100	384,00
JP44173	SPARE LEVEL CONT. C/W END SUPPORT 10M	520,00
JP44174	SPARE ROD C/W FLOAT	82,00
JP44647	SPARE PROFILED JOINT HEBEFIX	43,00
JP44749	SPARE COMPLI 300 TANK, COMPL.	1215,00
JP44859	SPARE COMPLI 400 TANK, COMPL.	1298,00
JP44860	SPARE COMPLI 500/01 TANK, COMPL.	1488,00
JP44861	SPARE COMPLI 1000/05 TANK, COMPL.	1934,00
JP44862	SPARE COMPLI 600+1200/02 TANK	2676,00
JP45056	SPARE TANK COMPLI 400, VERS.8	1024,00
JP45057	SPARE COMPLI 500 TANK, COMPLETE	1488,00
JP45058	SPARE COMPLI 1000/04 TANK, COMPLETE	2433,00
JP45059	SPARE COMPLI 600/01 TANK, COMPLETE	2676,00
JP45060	SPARE COMPLI 1200/01 TANK, COMPLETE	2676,00
JP45061	SPARE COMPLI 1500 TANK, COMPLETE	3055,00
JP45080	SPARE CABLE GLAND OXYLIFT/ -PERL	53,00
JP45081	SPARE MOTORUNIT COMPL. OXYPERL 3 /2	325,00
JP45082	SPARE AERATORHOUSING OXYPERL 3 /02	67,00
JP45083	SPARE PROPELLER COMPL. OXYPERL 3 /02	27,10
JP45084	SPARE CABLE GLAND 11B- 10M	69,00
JP45091	SPARE CONTROL UNIT HEBEFIX PLUS	181,00
JP45092	SPARE ACTIVATED CARBON FILTER 1	25,80
JP45093	SPARE FLOAT HEBEFIX PLUS	58,00
JP45094	SPARE OUTLET HEBEFIX PLUS	52,00
JP45095	SPARE COVER HEBEFIX PLUS	94,00
JP45096	SPARE U3KS HEBEFIX PLUS	480,00
JP45097	SPARE OUTLET HEBEFIX PLUS	59,00
JP45098	SPARE PLUG IN SEAL D40XD47	10,90
JP45099	SPARE PLUG IN SEAL D50XD59	12,40
JP45100	SPARE COLLAR 67/50	33,00
JP45101	SPARE TANK UNDERPART HEBEFIX PLUS	191,00
JP45109	SPARE COMPENSATING DISC - 2PC	16,20
JP45118	SPARE RETAINER SPARE GR35...GR50	101,00
JP45119	SPARE RETAINER SPARE GR65...GR101	148,00
JP45120	SPARE RETAINER SPARE GR151...GR200	257,00
JP45123	SPARE LEVER GR200S	386,00
JP45124	SPARE GUIDE TUBE FIXATION	17,60
JP45125	SPARE COUPLING CLAW GR35/2	120,00

JP45126	SPARE COUPLING CLAW GR35/2-08	158,00
JP45127	SPARE COUPLING CLAW GR40/0	129,00
JP45128	SPARE COUPLING CLAW GR50/0	145,00
JP45129	SPARE COUPLING CLAW GR65/4	241,00
JP45130	SPARE COUPLING CLAW GR80/4	267,00
JP45131	SPARE COUPLING CLAW GR100/4+GR101/1	370,00
JP45132	SPARE COUPLING CLAW GR151/4	668,00
JP45133	SPARE COUPLING CLAW GR200/0	1202,00
JP45134	SPARE SEAL KIT GR35/2+GR40/0	13,80
JP45135	SPARE SEAL KIT GR50/0	16,30
JP45136	SPARE SEAL KIT GR65/4	23,10
JP45137	SPARE SEAL KIT GR80/4	23,10
JP45138	SPARE SEAL KIT GR100/4+GR101/1	27,10
JP45139	SPARE SEAL KIT GR151/4	37,00
JP45140	SPARE SEAL KIT GR200/0	84,00
JP45179	SPARE MODULE EX II	211,00
JP45180	SPARE MODULE EX III	243,00
JP45216	UTD SPARE GSM MODEM FOR SPARE	1410,00
JP45231	SPARE FLUSH VALVE UNIT FOR SPARE	2229,00
JP45380	SPARE DO2 MODULE	208,00
JP45381	SPARE DO4 MODULE	219,00
JP45382	SPARE DI8 MODULE	300,00
JP45383	SPARE I ² C BUS REPEATER	172,00
JP45386	SPARE TE MODULE	97,00
JP45387	SPARE I ² C BUSCABLE 0,3M	37,00
JP45388	SPARE I ² C BUSCABLE 0,6M	52,00
JP45467	SPARE IMPELLER 08/2 M	136,00
JP45468	SPARE IMPELLER 20/2 M PLUS	136,00
JP45469	SPARE CABLE GLAND 31A-10M	539,00
JP45471	SPARE VOLUTE WITH WEAR PLATE	332,00
JP45472	UTD SPARE CUTTER 08 - 20/2 M	145,00
JP45542	SPARE IMPELLER 25/2 M+ME	167,00
JP45547	SPARE CLAMP FOR FLUSHING TUBE TYP0	143,00
JP45583	SPARE CABLE GLAND 31A-15M	628,00
JP45584	SPARE CABLE GLAND 31A-20M	720,00
JP45585	SPARE BEARING SET 08-20	80,00
JP45594	SPARE COVER PLANCOFIX	71,00
JP45595	SPARE COVER (SMALL) PLANCOFIX	64,00
JP45596	SPARE GRID PLANCOFIX	72,00
JP45597	SPARE COVER FOR PLANCOFIX MOTOR	45,00
JP45598	SPARE FLOAT PLANCOFIX	39,00
JP45599	SPARE MICRO SWITCH PLANCOFIX	42,00
JP45600	SPARE SWITCH CAM PLANCOFIX	114,00
JP45601	SPARE MOTOR CLAMP PLANCOFIX	45,00
JP45602	SPARE MOTOR C/W 040 IMPELLER	451,00
JP45603	SPARE PIPE CONNECTOR PLANCOFIX	31,00
JP45604	SPARE ACCESSORIES SET PLANCOFIX	125,00
JP45605	SPARE HYDRAULIC SEAL KIT PLANCOFIX	29,80
JP45606	SPARE HOUSING SEAL KIT PLANCOFIX	71,00
JP45628	SPARE SET OF SEALS 08-20	58,00
JP45634	SPARE DUCKFOOT BEND GR35/2+GR40	292,00
JP45635	SPARE DUCKFOOT BEND GR50+50S	348,00
JP45636	SPARE DUCKFOOT BEND GR65/4	632,00
JP45637	SPARE DUCKFOOT BEND GR80/4	676,00
JP45638	SPARE DUCKFOOT BEND GR100/4	819,00

JP45639	SPARE DUCKFOOT BEND GR101/1	950,00
JP45640	SPARE DUCKFOOT BEND GR151/4+151S/2	1635,00
JP45641	SPARE DUCKFOOT BEND GR200S	2310,00
JP45655	SPARE SHAFT C/W BEARINGS 08/2M	223,00
JP45656	SPARE SHAFT C/W BEARINGS 20/2M	223,00
JP45657	SPARE WEAR PLATE 1	91,00
JP45698	SPARE SCREW SET DN 80, PE-PE	94,00
JP45699	SPARE SCREW SET 100, PE-PE	94,00
JP45700	SPARE SCREW SET 100, PE-PE	129,00
JP45701	SPARE SCREW SET DN 80, ST-ST	64,00
JP45702	SPARE SCREW SET 100, ST-ST	64,00
JP45703	SPARE SCREW SET 150, ST-ST	97,00
JP45761	SPARE U3KS HEBEFIX EXTRA	727,00
JP45768	SPARE VOLUTE CASING SET J67	351,00
JP45769	UTD SPARE STRUT TUBE J67	555,00
JP45770	SPARE SHAFT SET J67	101,00
JP45771	SPARE FLOAT SWITCH SET J67	101,00
JP45772	SPARE MOTOR SET J67	867,00
JP45773	SPARE MOTOR KD J67	867,00
JP45774	SPARE CONTROL UNIT KE J67	359,00
JP45775	SPARE CONTROL UNIT KD J67	359,00
JP45776	SPARE IMPELLER SET J67	110,00
JP45778	UTD SPARE TANK PUMP UC 10/4 BW	1449,00
JP45779	UTD SPARE TANK PUMP UC 15/4 BW	1449,00
JP45780	UTD SPARE UC 25/4 BW /1 TANK PUMP	1449,00
JP45781	UTD SPARE UC 25/2 BW /2 TANK PUMP	2612,00
JP45786	SPARE CONTROL UNIT BD46P	1951,00
JP45787	SPARE CONTROL UNIT BD610P	1951,00
JP45788	SPARE BASICLOGO AD 25P CONTROL UNIT	1023,00
JP45789	SPARE BASICLOGO AD 46P CONTROL UNIT	1068,00
JP45790	SPARE BASICLOGO AD610P CONTROL UNIT	1191,00
JP45791	SPARE ROTOR SHAFT D90-4/75 UC	222,00
JP45792	SPARE TOLERANCE RING 25X25 BN25-025	21,90
JP45793	SPARE VORTEX IMPELLER 10/4 BW	67,00
JP45794	SPARE VORTEX IMPELLER 15/4 BW	123,00
JP45795	SPARE VORTEX IMPELLER 25/4 BW	147,00
JP45807	SPARE GUIDE TUBE BRACKET PKS-B 800	69,00
JP45825	SPARE SCREW SET PE-ST DN80	89,00
JP45826	SPARE SCREW SET PE-ST DN 100	89,00
JP45827	SPARE SCREW SET PE-ST DN 150	124,00
JP45828	SPARE FLUSHING TUBE ACCES. TYPE 1-M	157,00
JP45829	SPARE FLUSHING TUBE TYPE 1	114,00
JP45830	SPARE FLUSHING TUBE FLANGE TYPE 1M	94,00
JP45869	SPARE CONTROL UNIT PSB+SH	2050,00
JP45870	SPARE CONTROL UNIT MH1 + MH2	2050,00
JP45871	SPARE CONTROL UNIT MH3	2860,00
JP45872	SPARE CONTROL UNIT MH4 + MH5	3553,00
JP45873	SPARE CONTROL UNIT MH6	3553,00
JP45881	SPARE NON RETURN VALVE R32	15,70
JP45882	SPARE NON RETURN VALVE R40	19,10
JP46001	SPARE LID SEAL HEBEFIX PLUS/EXTRA	27,10
JP46008	SPARE INLET SEAL DN150	54,00
JP46009	SPARE EL. CONNECT. DN 100, C1500/2500	94,00
JP46011	SPARE SCREW SET 3	18,60
JP46012	SPARE CABLE GLAND 14-10 M	191,00

JP46013	SPARE CABLE GLAND 11A-10 M	128,00
JP46014	SPARE CABLE GLAND 11C-10 M	140,00
JP46015	SPARE CAPACITOR 8µF	17,30
JP46016	SPARE CAPACITOR 20µF	23,00
JP46017	SPARE CAPACITOR 25F	25,80
JP46018	SPARE TOP COVER 1	75,00
JP46019	SPARE TOP COVER US/UB W/O FLOAT SWITCH	75,00
JP46020	SPARE SWITCH SHAFT 2	21,90
JP46021	SPARE SWITCH SHAFT 3	73,00
JP46022	SPARE FLOAT 2	36,00
JP46023	SPARE FLOAT SWITCH UB/ES	104,00
JP46024	SPARE FLOAT SWITCH UB/DS	104,00
JP46025	SPARE SWITCH CARTRIDGE	10,70
JP46027	SPARE STATOR + HOUSING E71-2/50B	429,00
JP46028	SPARE STATOR + HOUSING D71-2/50B	486,00
JP46029	SPARE STATOR + HOUSING E71-2/80A	506,00
JP46030	SPARE STATOR + HOUSING D71-2/80A	601,00
JP46031	SPARE STATOR + HOUSING E71-2/105A	744,00
JP46032	SPARE STATOR + HOUSING D71-2/105A	761,00
JP46033	SPARE STATOR + HOUSING E71-2/50V	445,00
JP46034	SPARE STATOR + HOUSING E71-2/80B	536,00
JP46035	SPARE ROTOR SHAFT 1, E71-2/50	156,00
JP46036	SPARE ROTOR SHAFT 1, D71-2/50	157,00
JP46037	SPARE ROTOR SHAFT 1, E71-2/80	204,00
JP46038	SPARE ROTOR SHAFT 1, D71-2/80	191,00
JP46039	SPARE ROTOR SHAFT 1, E71-2/105	225,00
JP46040	SPARE ROTOR SHAFT 1, D71-2/105	195,00
JP46041	SPARE SEAL SET 2	19,30
JP46042	SPARE BEARING SET 1	28,40
JP46043	SPARE MECHANICAL SEAL 2	46,00
JP46044	SPARE VOLUTE CASING US/UB 62-153	362,00
JP46045	SPARE VOLUTE CASING US 75-155	370,00
JP46046	SPARE OIL SCREW G 1/4 A	9,10
JP46047	SPARE FEET US SERIES	16,20
JP46048	SPARE STRAINER BASE US/UB 62-152	44,00
JP46049	SPARE FEET US HE SERIES	45,00
JP46050	SPARE WEAR PLATE US/UB 62-253	17,90
JP46051	SPARE WEAR PLATE US 75-155	16,90
JP46052	SPARE IMPELLER US/UB 62-75	52,00
JP46053	SPARE IMPELLER US/UB 102-105	54,00
JP46054	SPARE IMPELLER US/UB 152-155E	82,00
JP46055	SPARE IMPELLER US/UB 152-155D	82,00
JP46056	SPARE CONTACTOR 2	104,00
JP46061	SPARE PLUG SYSTEM PERROT	27,10
JP46062	SPARE SPRING COTTER	19,10
JP46063	SPARE BALL VALVE EXT. PKSB 800-32	163,00
JP46064	SPARE PRESSURE OUTLET COMPLETE	582,00
JP46065	SPARE TIE BAR WITH SCREWS PKSB 800-32	211,00
JP46066	SPARE COUPLING UNIT SET PKS-B 800-32	142,00
JP46067	SPARE GUIDE RAIL BRACK. PKS-A 800-D32	101,00
JP46068	SPARE STOP VALVE EXT. PKS-A 800-D32	168,00
JP46069	SPARE PRESSURE OUTLET SET PKS-A800	1204,00
JP46070	SPARE TIE BAR SET PKS-A 800 D-32	855,00
JP46071	SPARE COUPLING UNIT SET PKS-A 800-D32	116,00
JP46072	SPARE GUIDE TUBES PKS-A 800-D32	64,00

JP46074	SPARE SET OF SEALS COMPLI 1500/2500	81,00
JP46075	SPARE PUMP PEDESTAL C.1500/2500	666,00
JP46076	SPARE FEET SUPPORT C.1500/2500	157,00
JP46116	SPARE CABLE GLAND 12-15 M	140,00
JP46161	SPARE LID FOR STAINLESS STEEL COMPLI	314,00
JP46165	SPARE PLUG COMPLI STAINLESS STEEL	93,00
JP46168	SPARE PUMP RETAINER COMPLI ST. STEEL	48,00
JP46169	SPARE VENT. FOR COMPLI STAINL. STEEL	80,00
JP46170	SPARE FOOT FOR COMPLI STAINL. STEEL	58,00
JP46171	SPARE FIXATION SET COMPLI ST. STEEL	97,00
JP46172	SPARE CLAMP. FLANGE COMPLI ST. STEEL	133,00
JP46182	SPARE COTTER PINS 1,6 x 20 - 10PC	19,50
JP46183	SPARE LOAD BEARING LABEL SET	38,00
JP46184	SPARE CHAIN JOINING LINK	156,00
JP46194	SPARE TOP COVER OXYPERL 5/ 01	73,00
JP46195	SPARE MOTOR UNIT OXYPERL 5/ 01	391,00
JP46196	SPARE AERATOR HOUSING OXYPERL 5/ 01	68,00
JP46197	SPARE PROPELLER OXYPERL 5/ 01	43,00
JP46210	SPARE STATOR+HOUSING M E90-2/75	1293,00
JP46211	SPARE STATOR+HOUSING M D90-2/110	1094,00
JP46214	SPARE BEARING SET 25-45	91,00
JP46215	SPARE SEAL SET 25-45	24,70
JP46216	SPARE BEARING HOUSING 2	268,00
JP46217	SPARE BEARING HOUSING 3	489,00
JP46218	SPARE IMPELLER 35/2 M	167,00
JP46219	SPARE IMPELLER 36/2 M	167,00
JP46220	SPARE IMPELLER 45/2 M	244,00
JP46221	SPARE SPIRAL HOUSING 25-36/2 M	322,00
JP46222	SPARE SPIRAL HOUSING 45/2 M	500,00
JP46223	SPARE CUTTER 25 - 45/2M	145,00
JP46225	SPARE CABLE GLAND 31-10M	621,00
JP46226	SPARE SPIRAL HOUSING TANDEM	384,00
JP46227	SPARE TANDEM CONNECTING FLANGE	1900,00
JP46228	SPARE CONNECTION RAIL TANDEM	158,00
JP46259	SPARE CABLE GLAND 21A-10 M	375,00
JP46260	SPARE CABLE GLAND 21-10 M	267,00
JP46263	SPARE SCREW SET 2	16,20
JP46266	SPARE FLOAT SWITCH US/UB 151/251/253	128,00
JP46267	SPARE STATOR + HOUSING D90-2/75E	930,00
JP46268	SPARE STATOR + HOUSING E90-2/75D	1138,00
JP46269	SPARE BEARING SET 2	73,00
JP46270	SPARE ROTOR SHAFT 1, D90-2/75	179,00
JP46271	SPARE ROTOR SHAFT 1, E90-2/75	213,00
JP46272	SPARE SEAL SET US/UB 151-253	37,00
JP46273	SPARE WEAR PLATE RUBBERISED	63,00
JP46274	SPARE IMPELLER US 151	155,00
JP46275	SPARE IMPELLER US/UB 251	155,00
JP46276	SPARE STRAINER BASE US/UB 151/251	79,00
JP46277	SPARE VOLUTE CASING US 151/251	421,00
JP46278	SPARE CABLE 3	465,00
JP46279	SPARE VOLUTE CASING US 253	488,00
JP46347	SPARE ALARM UNIT AG	288,00
JP46348	SPARE DISCONNECTING BARRIER 40140	125,00
JP46351	SPARE MICROSWITCH 1	33,00
JP46352	SPARE MICRO SWITCH 2	33,00

JP46353	SPARE CAPACITOR 6µF	13,60
JP46354	SPARE SEAL SET 1	12,00
JP46355	SPARE ELBOW G 1 1/4	11,30
JP46356	SPARE RUBBER FLAP U3	6,80
JP46357	SPARE CAPACITOR 8µF	20,40
JP46358	SPARE IMPELLER U3	33,00
JP46359	SPARE VOLUTE CASING U3K	58,00
JP46360	SPARE STRAINER BASE 1	20,80
JP46361	SPARE MOTOR UNIT U3	288,00
JP46362	SPARE MOTOR UNIT U3 SPEZIAL	310,00
JP46363	SPARE IMPELLER U5	42,00
JP46364	SPARE VOLUTE CASING U5	58,00
JP46365	SPARE STRAINER BASE 2	23,10
JP46366	SPARE RUBBER FLAP U5	16,00
JP46367	SPARE STRAINER BASE 3	27,10
JP46368	SPARE VOLUTE CASING U6	54,00
JP46369	SPARE IMPELLER U6	46,00
JP46370	SPARE MOTOR SEAL SET 1	41,00
JP46371	SPARE MOTOR CONTACTOR 1	104,00
JP46372	SPARE TOP COVER U6K ES	126,00
JP46373	SPARE TOP COVER U6K DS	224,00
JP46374	SPARE CAPACITOR 10 µF	21,90
JP46375	SPARE MOTOR UNIT U6 E	463,00
JP46376	SPARE MOTOR UNIT U6 D	504,00
JP46378	SPARE IMPELLER U3 SPEZIAL	71,00
JP46379	SPARE TOP COVER U3K, 10M	112,00
JP46380	SPARE TOP COVER U3KS, 4m	112,00
JP46381	SPARE TOP COVER U3K SPEZIAL, 10M	172,00
JP46382	SPARE TOP COVER U3KS SPECIAL, 4M	129,00
JP46383	SPARE TOP COVER U3KS SPECIAL, 10M	172,00
JP46384	SPARE TOP COVER U3KS, 10M	158,00
JP46385	SPARE SEAL SET 2	21,90
JP46387	SPARE COVER U5K	27,10
JP46388	SPARE MOTOR UNIT U5	391,00
JP46389	SPARE TOP COVER U5K, 10M	112,00
JP46390	SPARE TOP COVER U5KS, 4M	112,00
JP46391	SPARE TOP COVER U5KS, 10M	158,00
JP46454	SPARE IMPELLER US 253 D/DS	155,00
JP46463	SPARE INSTALLATION SET PSV	120,00
JP46465	SPARE MC3.3 C/W SOFTWARE	784,00
JP46466	SPARE MC3.3 C/W HD04 SOFTWARE	784,00
JP46551	SPARE ROTOR SHAFT 2, E71-2/80	239,00
JP46552	SPARE ROTOR SHAFT 2, D71-2/80	197,00
JP46553	SPARE VOLUTE CASING 08/2 M	353,00
JP46555	SPARE IMPELLER MULTICUT 08/26 M	530,00
JP46556	SPARE IMPELLER MULTICUT 08/2 ME	167,00
JP46557	SPARE WEAR PLATE 2	132,00
JP46559	SPARE SHIM RING SET 1	46,00
JP46560	SPARE SCREW SET 4	13,30
JP46561	SPARE ROTOR SHAFT 2, D71-2/80	253,00
JP46562	SPARE ROTOR SHAFT 2, D71-2/105	218,00
JP46563	SPARE SCREW SET 5	11,80
JP46564	SPARE ROTORSHAFT 1, D90-2/110	226,00
JP46565	SPARE ROTORSHAFT 2, D90-2/75	180,00
JP46566	SPARE ROTORSHAFT 1, E90-2/110	273,00

JP46567	SPARE MECHANICAL SEAL 4	75,00
JP46568	SPARE CUTTER 75 - 76/2 M	145,00
JP46571	SPARE SHIM RING SET 2	46,00
JP46572	SPARE CONNECTOR 7-PIN	14,80
JP46573	SPARE CONNECTOR 10-PIN	18,50
JP46574	SPARE HOUSING + STATOR D112-2/140D	2746,00
JP46575	SPARE CABLE 21B-10M	865,00
JP46576	SPARE CABLE 31B-10M	1138,00
JP46577	SPARE ROTOR SHAFT D112-2/140	1032,00
JP46578	SPARE BEARING COVER 1	131,00
JP46579	SPARE BEARING HOUSING 4	1056,00
JP46580	SPARE SEAL COVER	211,00
JP46581	SPARE IMPELLER MULTICUT 75	416,00
JP46582	SPARE IMPELLER MULTICUT 76	651,00
JP46583	SPARE SEAL SET 6	240,00
JP46584	SPARE WEAR PLATE 3	373,00
JP46585	SPARE VOLUTE CASING 75-76 M	727,00
JP46586	SPARE BEARING SET 5	193,00
JP46587	SPARE MECHANICAL SEAL 5	189,00
JP46588	SPARE SCREW SET 7	36,00
JP46632	SPARE CABLE GLAND 31A-25M	810,00
JP46633	SPARE CABLE GLAND 31A-30M	899,00
JP46634	SPARE CABLE GLAND 31B-15M	1344,00
JP46635	SPARE CABLE GLAND 31B-20M	1547,00
JP46636	SPARE CABLE GLAND 31B-25M	1751,00
JP46637	SPARE CABLE GLAND 31B-30M	1842,00
JP46709	SPARE SUBM. BALL SWITCH 9,5M STURDY	240,00
JP46710	SPARE VORTEX IMPELLER 15/4 BW1, 15/4CW1	254,00
JP46711	SPARE VORTEX IMPELLER 25/4 BW1, 25/4CW1	273,00
JP46712	SPARE VORTEX IMPELLER 35/4 BW1, 35/4CW1	317,00
JP46713	SPARE VORTEX IMPELLER 25/2 AW	157,00
JP46714	SPARE VORTEX IMPELLER 35/2 AW	175,00
JP46715	SPARE VORTEX IMPELLER 25/2 BW1	193,00
JP46716	SPARE VORTEX IMPELLER 35/2 BW1	203,00
JP46717	SPARE VOLUTE CASING CW1	928,00
JP46718	SPARE VOLUTE CASING BW1	770,00
JP46719	SPARE VOLUTE CASING AW1	526,00
JP46720	SPARE BEARING HOUSING 9	465,00
JP46721	SPARE VORTEX IMPELLER SSR	627,00
JP46722	SPARE PIPE NIPPLE 1/4 HAMBURG	43,00
JP46723	SPARE VOLUTE CASING CW2	2011,00
JP46724	SPARE BEARING SET 9	29,80
JP46728	SPARE MOTOR SEALS 3	41,00
JP46753	UTD SPARE UC 9/4 BW TANK PUMP /2	1372,00
JP46754	SPARE UC 10/4 BWE/1 TANK PUMP	1478,00
JP46761	SPARE ROTOR SHAFT D90-4/50 UC	203,00
JP46766	SPARE NON RETURN VALVE SET R80/4	118,00
JP46767	SPARE NON RETURN VALVE SET R101/3	123,00
JP46768	SPARE NON RETURN VALVE SET R80G/4	199,00
JP46769	SPARE NON RETURN VALVE SET R101G/3	218,00
JP46770	SPARE SHAFT FOR NON RETURN VALVE R80G/4	138,00
JP46771	SPARE SHAFT FOR NON RETURN VALVE R101G/4	179,00
JP46772	SPARE NON RETURN VALVE SET R80/3	118,00
JP46773	SPARE NON RETURN VALVE SET R101/2	123,00
JP46774	SPARE BALL + O-RING K80	248,00

JP46775	SPARE BALL + O-RINGS K50/KE40	80,00
JP46776	SPARE VORTEX IMPELLER 10/4 CW1	375,00
JP46781	SPARE PLUG-IN UNIT DRAINAGE SET	284,00
JP46782	SPARE CABLE 11D-20M	185,00
JP46783	SPARE HOSE CONNECTION 1 1/4" AG	24,20
JP46784	SPARE TAPER NIPPLE 1 1/4 X 1 1/4	31,00
JP46785	SPARE ANTI TWIST DEVICE	114,00
JP46801	SPARE ROTOR SHAFT UC 10/4 BWE	246,00
JP46802	SPARE IMPELLER CONNECTION 500/1000 BW	12,90
JP46803	SPARE IMPELLER CONNECTION 1010/4 BWE	57,00
JP46805	SPARE IMPELLER CONNECTION 525/2-1035/2	57,00
JP46806	SPARE MOTOR SEALS 4	10,50
JP46807	SPARE SET OF SEALS 10	16,30
JP46810	SPARE BASICLOGO AD 00P CONTROL UNIT	912,00
JP46812	SPARE DUPLEX FLAP RUBBERISED	113,00
JP46813	SPARE HOUSING NON RETURN VALVE COMPLI	735,00
JP46814	SPARE CONNECTION DN70	37,00
JP46815	SPARE SUMP SEAL DN 1000	134,00
JP46816	SPARE SUMP SEAL DN 625	134,00
JP46817	SPARE SCREW SET CLAW 40	63,00
JP46818	SPARE SCREW SET CLAW 65	66,00
JP46819	SPARE SCREW SET CLAW 80	69,00
JP46820	SPARE TANK COMPLI 100/4	401,00
JP46821	SPARE UC 08/2 ME TANK PUMP COMPLI 100	2427,00
JP46822	SPARE UC 08/2 M TANK PUMP COMPLI 100	2427,00
JP46824	SPARE UC 20/2 M TANK PUMP COMPLI 100	3148,00
JP46825	SPARE BASICLOGO AD 08/2 MEP CONTROL UNIT	1374,00
JP46827	SPARE ROTOR SHAFT E71-2/80 UC	265,00
JP46828	SPARE ROTOR SHAFT D71-2/80 UC	202,00
JP46829	SPARE SET OF SEALS 11	42,00
JP46830	SPARE BEARING SET 10	45,00
JP46832	SPARE TANK COMPLI 500	1204,00
JP46833	SPARE UC 08/2 ME TANK PUMP C.500/1000	2427,00
JP46834	SPARE UC 08/2 M TANK PUMP, C 500/1000	2427,00
JP46835	SPARE UC 20/2 M COMPLI 500/1000	3148,00
JP46836	SPARE TANK COMPLI 1000 M	1393,00
JP46837	SPARE NON RETURN VALVE DR40 COMPLI 1000	333,00
JP46838	SPARE SUMP CONNECTION SET SH/MH	133,00
JP46839	SPARE PCB AD25	486,00
JP46840	SPARE COMPRESSOR MH 2	7523,00
JP46841	SPARE VALVE FLAP COMPLI 300	80,00
JP46843	UTD SPARE CABLE 11A-4M	68,00
JP46845	SPARE BEARING HOUSING UC /4 BW	197,00
JP46846	SPARE PCB AD00	344,00
JP46850	SPARE UC 9/4 C, SHAFT, BEARINGS, IMPELL.	348,00
JP46904	SPARE CATCH HANGER - 20 PC	31,00
JP46919	SPARE TOP COVER U6K E	79,00
JP46920	SPARE TOP COVER U6K D	175,00
JP46921	SPARE CABLE GLAND OXYLIFT W/O FLOAT	45,00
JP46922	SPARE CABLE GLAND OXYLIFT C/W FLOAT	54,00
JP46923	SPARE IMPELLER OXYLIFT	31,00
JP46924	SPARE MOTOR UNIT OXYLIFT 2	325,00
JP46925	SPARE CABLE 11B- 1,5	41,00
JP46926	SPARE CABLE 11B- 4M	49,00
JP46927	SPARE CABLE 11B- 20M	105,00

JP46928	SPARE TOP COVER OXYLIFT/OXYPERL	54,00
JP46929	SPARE TOP COVER OXYLIFT 2S	54,00
JP46930	SPARE CABLE GLAND OXYPERL 5	45,00
JP46934	SPARE VOLUTE OXYLIFT 2	54,00
JP46980	SPARE CABLE 18-10M	201,00
JP46987	SPARE CUTTER PLATE 75 - 76/2 M	112,00
JP46999	SPARE FLOAT 3	38,00
JP47000	SPARE PUSH BUTTON TRIAL RUN	16,30
JP47001	SPARE SWITCH K2 PLUS	24,30
JP47002	SPARE CONTROL UNIT K2 PLUS	94,00
JP47003	SPARE NON RETURN VALVE K2 PLUS	15,30
JP47004	SPARE LIP SEAL RING K2 PLUS	11,30
JP47005	SPARE IMPELLER CONDESATE PUMP	19,20
JP47006	SPARE CABLE 41	22,00
JP47007	SPARE CONDENSATE TANK K2 PLUS	80,00
JP47008	SPARE TOP COVER K2 + K2 PLUS	44,00
JP47009	SPARE COMPONENT RECEIVER K2 PLUS	46,00
JP47010	SPARE LOCKING DEVICE K2 PLUS	12,00
JP47034	SPARE ELECTRODE AGE, 10M	215,00
JP47038	SPARE ROTORSHAFT 1, D90-2/75	185,00
JP47039	SPARE ROTORSHAFT 1, D90-2/110	243,00
JP47040	SPARE ROTORSHAFT 1, D90-4/75	207,00
JP47041	SPARE ROTORSHAFT 1, D90-4/110	259,00
JP47042	SPARE STATOR + HOUSING D90-4/75D	894,00
JP47043	SPARE SHAFT COVER 2	33,00
JP47044	SPARE BEARING SET 8	843,00
JP47045	SPARE STATOR + HOUSING D90-4/110C	1166,00
JP47046	SPARE IMPELLER FIXATION 150-300	171,00
JP47047	SPARE IMPELLER 10/2 A1	452,00
JP47048	SPARE IMPELLER 15/2 A1	477,00
JP47049	SPARE IMPELLER 25/2 A2	401,00
JP47050	SPARE IMPELLER 35/2 A2	447,00
JP47051	SPARE IMPELLER 25/2 B1	436,00
JP47052	SPARE IMPELLER 35/2 B2	444,00
JP47053	SPARE IMPELLER 10/4 B1	478,00
JP47054	SPARE IMPELLER 15/4 B3	478,00
JP47055	SPARE IMPELLER 25/4 B4	811,00
JP47056	SPARE IMPELLER 35/4 B4	821,00
JP47057	SPARE IMPELLER 25/4 C1	968,00
JP47058	SPARE IMPELLER 35/4 C1	948,00
JP47059	SPARE IMPELLER FIXATION 10-35	57,00
JP47060	SPARE VOLUTE CASING A1	603,00
JP47061	SPARE VOLUTE CASING A2	643,00
JP47062	SPARE VOLUTE CASING B1	736,00
JP47063	SPARE VOLUTE CASING B2	842,00
JP47064	SPARE VOLUTE CASING B3	817,00
JP47065	SPARE VOLUTE CASING B4	1001,00
JP47066	SPARE VOLUTE CASING C1	1459,00
JP47067	SPARE VOLUTE CASING C1 UC	1459,00
JP47068	SPARE BEARING COVER 5	426,00
JP47069	SPARE BEARING HOUSING 6	437,00
JP47070	SPARE BEARING HOUSING 7	478,00
JP47071	SPARE BEARING HOUSING 8	486,00
JP47072	SPARE WEAR RING 1	236,00
JP47073	SPARE WEAR RING 2	225,00

JP47074	SPARE WEAR RING 3	230,00
JP47076	SPARE SCREW SET 8	29,80
JP47077	SPARE SET OF SEALS 7	49,00
JP47089	SPARE STATOR + HOUSING D160-2/140C	8504,00
JP47090	SPARE STATOR + HOUSING D160-2/250B	10629,00
JP47091	SPARE STATOR + HOUSING D160-4/160B	7998,00
JP47092	SPARE STATOR + HOUSING D160-4/200B	9279,00
JP47093	SPARE STATOR + HOUSING D160-4/250B	10528,00
JP47095	SPARE CABLE 21C-10M	1469,00
JP47097	SPARE CABLE 31C-10M	1536,00
JP47098	SPARE SCREW SET 9	49,00
JP47099	SPARE SET OF SEALS 8	106,00
JP47100	SPARE BEARING COVER 2	271,00
JP47101	SPARE VOLUTE CASING B6-4	1576,00
JP47102	SPARE VOLUTE CASING C3/4-1	3066,00
JP47103	SPARE VOLUTE CASING C6-1	6207,00
JP47104	SPARE VOLUTE CASING C7	4566,00
JP47105	SPARE WEAR RING 8	470,00
JP47106	SPARE WEAR RING 9	412,00
JP47108	SPARE BEARING SET 6	516,00
JP47109	SPARE ROTORSHAFT D160-4/160	1513,00
JP47110	SPARE ROTORSHAFT D160-2/140	1407,00
JP47111	SPARE ROTORSHAFT D160-4/200	1684,00
JP47112	SPARE ROTORSHAFT D160-2/250	1768,00
JP47113	SPARE ROTORSHAFT D160-4/250	1970,00
JP47114	SPARE MECHANICAL SEAL 6	973,00
JP47115	SPARE MECHANICAL SEAL 7	846,00
JP47116	SPARE SHAFT COVER 1	296,00
JP47117	SPARE IMPELLER 200/2 B6	2457,00
JP47118	SPARE IMPELLER 300/2 B6	2115,00
JP47119	SPARE IMPELLER 150/4 C3	2183,00
JP47120	SPARE IMPELLER 151+230/4 C3/C7	2457,00
JP47121	SPARE IMPELLER 231+300/4 C4/C7	2516,00
JP47122	SPARE IMPELLER 150/4 C6	2183,00
JP47123	SPARE IMPELLER 230/4 C6 + 151/4 C6	2457,00
JP47124	SPARE IMPELLER 300/4 C6 + 231/4 C6	2516,00
JP47125	SPARE PARTITION FLANGE 1	914,00
JP47126	SPARE PARTITION FLANGE 2	1027,00
JP47127	SPARE PARTITION FLANGE 3	1127,00
JP47128	SPARE BEARING HOUSING 5	1374,00
JP47129	SPARE BEARING HOUSING 6	1293,00
JP47137	SPARE BEARING SET 7	247,00
JP47138	SPARE SET OF SEALS 9	112,00
JP47139	SPARE SCREW SET 10	57,00
JP47140	SPARE MECHANICAL SEAL 9	199,00
JP47141	SPARE STATOR + HOUSING D112-2/110C	2715,00
JP47142	SPARE STATOR + HOUSING D112-4/110D	2441,00
JP47143	SPARE STATOR + HOUSING D112-4/140D	2546,00
JP47144	SPARE STATOR + HOUSING D112-4/200B	5094,00
JP47145	SPARE IMPELLER 55/2 B2	1320,00
JP47146	SPARE IMPELLER 75/2 B5	1495,00
JP47147	SPARE IMPELLER 100/2 B5	1561,00
JP47148	SPARE ROTORSHAFT D112-2/110	571,00
JP47149	SPARE ROTORSHAFT D112-2/140	647,00
JP47150	SPARE ROTORSHAFT D112-2/200	1064,00

JP47151	SPARE ROTORSHAFT D112-4/110	620,00
JP47152	SPARE ROTORSHAFT D112-4/140	647,00
JP47153	SPARE VOLUTE CASING B5-3	992,00
JP47154	SPARE VOLUTE CASING B6-4 UC	1715,00
JP47155	SPARE BEARING COVER 3	176,00
JP47156	SPARE IMPELLER 55/4 B6	1320,00
JP47157	SPARE IMPELLER 75/4 B6	1495,00
JP47158	SPARE BEARING HOUSING 6	948,00
JP47159	SPARE PARTITION FLANGE 5	689,00
JP47160	SPARE PARTITION FLANGE 6	867,00
JP47161	SPARE PARTITION FLANGE 4	695,00
JP47162	SPARE BEARING HOUSING 7	640,00
JP47163	SPARE WEAR RING 11	262,00
JP47164	SPARE WEAR RING 12	282,00
JP47165	SPARE WEAR RING 4	274,00
JP47166	SPARE WEAR RING 5	465,00
JP47167	SPARE WEAR RING 6	635,00
JP47168	SPARE WEAR RING 7	564,00
JP47169	SPARE ROTORSHAFT D112-4/200	1238,00
JP47170	SPARE IMPELLER 55/4 C5	1320,00
JP47171	SPARE IMPELLER 75/4 C5	1495,00
JP47172	SPARE IMPELLER 55/4 C2	1320,00
JP47173	SPARE IMPELLER 75/4 C2	1495,00
JP47174	SPARE IMPELLER 100/4 C2+C5, 76/4 C5	1561,00
JP47175	SPARE VOLUTE CASING C2-3	3152,00
JP47176	SPARE VOLUTE CASING C5-2	1572,00
JP47177	SPARE VOLUTE CASING C5-2 UC	1572,00
JP47178	SPARE STATOR + HOUSING D112-4/200B	4750,00
JP47179	SPARE CABLE 21B1-10M	865,00
JP47180	SPARE CABLE 31B1-10M	1138,00
JP47181	SPARE SHAFT COVER 3	23,00
JP47182	SPARE IMPELLER FIXATION 55-100 A	75,00
JP47183	SPARE IMPELLER FIXATION 55-100 B	75,00
JP47185	SPARE PUMP UNIT WCFIX PLUS	348,00
JP47186	SPARE COVER WCFIX PLUS	33,00
JP47187	SPARE HOOD WCFIX PLUS	59,00
JP47188	SPARE VENTILATION VALVE FOR TANK	11,60
JP47189	SPARE PCB WCFIX PLUS	116,00
JP47190	SPARE CAPACITOR P2 10µF	29,80
JP47191	SPARE DISCHARGE CONNECTION WCFIX PLUS	36,00
JP47192	SPARE REFLUX VALVE WCFIX PLUS	18,50
JP47193	SPARE PRESSURE SWITCH SLOW MOTION CONT.	67,00
JP47194	SPARE TANK WCFIX PLUS	297,00
JP47195	SPARE PRIORITY VALVE WCFIX PLUS	12,30
JP47196	SPARE PILOT TUBE WCFIX PLUS	28,40
JP47197	SPARE WC CONNECTION WCFIX PLUS	37,00
JP47198	SPARE DN 100 COVER WCFIX PLUS	22,40
JP47199	SPARE DN 50 COVER WCFIX PLUS	19,70
JP47200	SPARE MOTOR WCFIX PLUS	325,00
JP47201	SPARE IMPELLER WCFIX PLUS	33,00
JP47202	SPARE CABLE 42	22,00
JP47203	SPARE MOTOR SEALING WCFIX PLUS	16,30
JP47204	SPARE MOTOR RECEIVER AND HOUSING	59,00
JP47205	SPARE FILTER HOUSING	21,80
JP47221	SPARE CABLE 16-10M	158,00

JP47231	SPARE COUPLING CLAW GR35/0+1	206,00
JP47232	SPARE VORTEX IMPELLER 55/4 CW2	647,00
JP47233	SPARE VORTEX IMPELLER 75/4 CW2	993,00
JP47285	SPARE CONTROL UNIT BD610 ECP, C1010/4BWE	1951,00
JP47286	SPARE CONTROL UNIT BD25 P	1951,00
JP47287	SPARE COLLAR 70 HTU	31,00
JP47288	SPARE MOTOR PUMP UNIT COMPLI 300 E	1576,00
JP47289	SPARE ROTOR SHAFT E71-2/80	206,00
JP47290	SPARE VORTEX IMPELLER 9/4 BW+10/4 BWE	94,00
JP47291	SPARE SCREW SET 11	15,10
JP47292	SPARE COMPRESSOR MH 3	9851,00
JP47293	SPARE COMPRESSOR MH 4	12234,00
JP47294	SPARE COMPRESSOR MH 5	15378,00
JP47295	SPARE COMPRESSOR MH 6	16930,00
JP47296	SPARE COMPRESSOR MH 1 + OIL LEVEL	8295,00
JP47297	SPARE COMPRESSOR MH 2 + OIL LEVEL	9032,00
JP47298	SPARE COMPRESSOR MH 3 + OIL LEVEL	11244,00
JP47299	SPARE COMPRESSOR MH 4 + OIL LEVEL	14359,00
JP47300	SPARE COMPRESSOR MH 5 + OIL LEVEL	14807,00
JP47301	SPARE COMPRESSOR MH 6 + OIL LEVEL	16062,00
JP47302	SPARE COMPRESSOR MH 1	6766,00
JP47303	SPARE PCB AD610	631,00
JP47304	SPARE PCB BD	304,00
JP47305	SPARE TANK COMPLI 1500/2500	2529,00
JP47306	SPARE FLOAT + LEVEL CONTROLLER	459,00
JP47308	SPARE NON RETURN VALVE COMPLI 1000	726,00
JP47309	SPARE VOLUTE CASING C100	556,00
JP47357	UTD SPARE SYNTHETIC HOSE NW38	110,00
JP47367	SPARE COVER ATB	53,00
JP47389	SPARE UC10/4 BWE, SHAFT,BEARINGS,IMPELL.	406,00
JP47390	SPARE VOLUTE CASING MULTICUT C. 500/1000	317,00
JP47391	SPARE ROTORSHAFT 1, E71-2/80	254,00
JP47393	SPARE REPLACEMENT TANK BAUFIX 50	370,00
JP47394	SPARE PROFILED SEAL BAUFIX	37,00
JP47395	SPARE CONNECTION SET INTERNAL BAUFIX 50	106,00
JP47396	SPARE CONNECTION SET INT. BAUFIX 100/3	106,00
JP47397	SPARE TANK BAUFIX 100	416,00
JP47398	SPARE SET OF SEALS TANDEM	73,00
JP47399	SPARE CLUTCH J67	38,00
JP47413	SPARE TANK PUMP UC10/4 BWE W/O CABLE	1433,00
JP47501	SPARE CABLE 31A-5M	449,00
JP47503	SPARE TANK WCFIX 260+A	297,00
JP47504	SPARE MOTOR UNIT WCFIX 260+A	325,00
JP47506	SPARE MOTOR SEAL WCFIX 260/A	16,30
JP47507	SPARE MOTOR RECEIVER+HOUSING WCFIX 260/A	92,00
JP47508	SPARE PILOT TUBE WCFIX 260	27,10
JP47509	SPARE PRESSURE SWITCH WCFIX 260/V	67,00
JP47510	SPARE TOP COVER WCFIX 260	33,00
JP47511	SPARE VENTILATION VALVE WCFIX 260	13,20
JP47512	SPARE VENTILATION HOSE WCFIX 260	11,80
JP47513	SPARE PRINTED CONTROL BOARD WCFIX 260	79,00
JP47514	SPARE PRINTED CONTROL BOARD WCFIX 260A/V	123,00
JP47515	SPARE CAPACITOR 6µF	15,60
JP47516	SPARE RUBBER FEET WCFIX 260/V	33,00
JP47517	SPARE WC CONNECTION WCFIX 260	37,00

JP47518	SPARE TOP COVER WCFIX 260	59,00
JP47519	SPARE BOUYANCY DEVICE WCFIX 260	21,80
JP47520	SPARE PRESSURE OUTLET WCFIX 260	46,00
JP47521	SPARE IMPELLER WCFIX 260/V	22,00
JP47522	SPARE CABLE 43	22,00
JP47523	SPARE TANK WCFIX 260V	297,00
JP47524	SPARE VOLUTE CASING WCFIX 260V	63,00
JP47525	SPARE MOTOR SEAL WCFIX 260V	16,30
JP47526	SPARE DRAINAGE HOSE	36,00
JP47527	SPARE INLET SEAL DN 50	37,00
JP47528	SPARE TOP COVER WCFIX 260 V	59,00
JP47530	SPARE OUTLET ELBOW WCFIX 260V	54,00
JP47531	SPARE PRIORITY VALVE FLAP WCFIX 260V	37,00
JP47533	UTD SPARE TANK HEBEFIX	139,00
JP47535	SPARE LID HEBEFIX	27,10
JP47536	SPARE OUTLET ELBOW D40	24,80
JP47537	SPARE RUBBER FEET HEBEFIX	38,00
JP47539	SPARE BALL + WASHER HEBEFIX	24,20
JP47540	SPARE SEALING PLUG 46/6,7	15,70
JP47542	SPARE ACTIVATED CARBON FILTER 2	11,00
JP47544	SPARE TANK HEBEFIX 100	486,00
JP47545	SPARE LID HEBEFIX 100	517,00
JP47546	SPARE SEAL RING HEBEFIX 100	64,00
JP47547	SPARE COVER HEBEFIX 100	27,10
JP47548	SPARE VENTILATION SET HEBEFIX 100	25,80
JP47549	SPARE HOSE CLAMP	16,90
JP47550	SPARE SEALING PLUG HEBEFIX	24,00
JP47551	SPARE OUTER CONNECTION SET HEBEFIX	73,00
JP47552	SPARE INNER CONNECTION SET HEBEFIX	203,00
JP47553	SPARE CONNECTION SET U3-U6 HEBEFIX 100	44,00
JP47554	SPARE CONNECTION SET US HEBEFIX 100	64,00
JP47555	SPARE BUOYANCY PROTECTION HEBEFIX 100	39,00
JP47556	SPARE TANK HEBEFIX 100H	692,00
JP47557	SPARE LID HEBEFIX 100H	475,00
JP47558	SPARE OUTER CONNECTION SET HEBEFIX 100H	405,00
JP47559	SPARE INLET SEAL HEBEFIX 100H	120,00
JP47560	SPARE NON RETURN VALVE HEBEFIX 100H	145,00
JP47563	SPARE CONNECTION SET INTERNAL BAUFIX 200	186,00
JP47565	SPARE PROFILED SEAL HEBEFIX 200	31,00
JP47566	SPARE BUOYANCY PROTECTION C/W FASTENERS	54,00
JP47567	SPARE DR 40 DUPLEX NON RETURN VALVE	140,00
JP47568	SPARE BUSHING HEBEFIX 200	29,80
JP47569	SPARE TIE BAR HEBEFIX	80,00
JP47606	SPARE PIPEWORK BAUFIX 200-50	200,00
JP47607	SPARE MANHOLE SEAL RING BAUFIX 200-50	106,00
JP47608	SPARE SUMP EXTENSION SKS	158,00
JP47609	SPARE SEAL SKS	63,00
JP47610	SPARE PIPEWORK SKS 200-40	520,00
JP47611	SPARE PIPE FAIRLEAD SKS 200-40	82,00
JP47613	SPARE PIPEWORK SKS 200-50	274,00
JP47614	SPARE PIPE FAIRLEAD SKS 200-50	106,00
JP47640	SPARE PIPEWORK HEBE/BAUFIX 200-50	247,00
JP47641	SPARE N. RETURN VALVE HEBE/BAUFIX 200-50	464,00
JP47642	SPARE CONNECTION SET HEBE/BAUFIX 200-50	131,00
JP47643	SPARE TOP COVER HEBEFIX 200	282,00

JP47644	SPARE LEVEL CONTROLLER C400 C/W O-RING	263,00
JP47645	SPARE AIR BELL + SCREW GLAND	53,00
JP47646	SPARE HOSE CONNECTOR	6,90
JP47650	SPARE ROTARY LEVEL CONTROLLER	502,00
JP47651	SPARE UC 25/4 C1 /5 TANK PUMP	5150,00
JP47652	SPARE UC 35/4 C1 /5 TANK PUMP	5447,00
JP47653	SPARE UC 55/4 C5 /5 TANK PUMP	9730,00
JP47654	SPARE UC 75/4 C5 /2 TANK PUMP	9943,00
JP47655	SPARE UC 75/4 B6 /4 TANK PUMP	11224,00
JP47656	SPARE UC 35/2 B2 TANK PUMP	4487,00
JP47657	SPARE UC 55/2 B2 TANK PUMP	8868,00
JP47658	SPARE UC 75/2 B5 TANK PUMP	10584,00
JP47659	SPARE UC 100/2 B5 TANK PUMP	14496,00
JP47660	SPARE UC 200/2 B6 TANK PUMP	14615,00
JP47661	SPARE PUMP PEDESTAL COMPLI 1500/2500	801,00
JP47662	SPARE CONTROL UNIT BS 1016 PD	7017,00
JP47663	SPARE CONTROL UNIT BS 1620 PD	7543,00
JP47665	SPARE FLANGE SUPPORT B5	489,00
JP47666	SPARE FLANGE SUPPORT B6	451,00
JP47667	SPARE FLANGE SUPPORT C1	417,00
JP47668	SPARE FLANGE SUPPORT C5	500,00
JP47669	SPARE FLANGE SUPPORT B2	641,00
JP47671	SPARE CONTACTOR 230V DIL EM-10	63,00
JP47672	SPARE HOURS METER, PLUG IN	91,00
JP47673	SPARE FUSE CARTRIDGE D01 16A 400V	21,10
JP47676	SPARE MAIN SWITCH 11 KW 3-POL. ISO	191,00
JP47677	SPARE AUXILLIARY SWITCH DIL M32-XHI11	36,00
JP47679	SPARE AUXILLIARY SWITCH 11 DIL EM	27,10
JP47680	SPARE PCB ADZ 00	316,00
JP47683	SPARE MOTOR PROTECTION 8A ETA	134,00
JP47684	SPARE PCB ADZ E	353,00
JP47686	SPARE PCB AE 2/1 ALARM EXTENSION MODULE	106,00
JP47687	SPARE ALARM SIGNALLER 12V/30MA	48,00
JP47688	SPARE PCB AM 2/3 ALARM MODULE	185,00
JP47689	SPARE AMMETER 0-10A, SNAP ON	283,00
JP47690	SPARE AMMETER 0-25A, KL 1,5 72X72	268,00
JP47691	SPARE ANALOGUE CONVERTER	157,00
JP47692	SPARE ENCLOSURE A, COMPL.	124,00
JP47693	SPARE PCB AD 08/2MEP	591,00
JP47694	SPARE HOURS METER 230V, SNAP ON	112,00
JP47695	SPARE HOURS METER 230V, FRONT INST.	98,00
JP47697	UTD SPARE FLASH LIGHT 230V D100 H106 g.	456,00
JP47698	SPARE HOSE FOR LEVEL CONTROLLER, 10M	89,00
JP47699	SPARE PRESSURE SWITCH ON 100/OFF 50 MM	94,00
JP47700	SPARE MEMBRANE PUMP	421,00
JP47701	SPARE ELEKTRODE 4-POLE NE-E	251,00
JP47702	SPARE ELEKTRODE DKG 10M	257,00
JP47704	SPARE MEMBRANE FOR AERATOR PUMP	97,00
JP47705	SPARE PCB ESM 4 MODULE	274,00
JP47706	SPARE PCB AD25EXM/3.1	495,00
JP47707	SPARE PCB AD46EXM/7.1	495,00
JP47708	SPARE PCB AD/AS-EXME /7.1	495,00
JP47709	SPARE PCB AD610EXM/7.1	495,00
JP47710	SPARE PCB C.300+ HEBEF.PLUS	98,00
JP47712	SPARE PCB AD00 E	344,00

JP47714	SPARE PCB AD 25 /7	486,00
JP47715	SPARE PCB AD 25 EX /3	486,00
JP47716	SPARE PCB AD 25EX1M /2	486,00
JP47717	SPARE PCB AD 46	486,00
JP47718	SPARE PCB AD 46 /3	486,00
JP47719	SPARE PCB AD 46 EX /3	486,00
JP47720	SPARE PCB AD 46 EXM /6	419,00
JP47721	SPARE PCB AD 610 EX /3	486,00
JP47722	SPARE PCB AD 610 EXM /6	419,00
JP47723	SPARE PCB AD 25 EX /4	486,00
JP47724	SPARE PCB AD 4/8 EXW /2	486,00
JP47725	SPARE PCB AD 46 EX /4	631,00
JP47726	SPARE PCB AD 610	631,00
JP47727	SPARE PCB AD 610 EX /4	631,00
JP47729	SPARE PCB ADZ 25	502,00
JP47730	SPARE PCB ADZ 46	502,00
JP47732	SPARE PCB BD	440,00
JP47733	SPARE PCB BD EXM /2	500,00
JP47734	SPARE PCB BD EXM /3	540,00
JP47735	SPARE PCB BD EX	465,00
JP47736	SPARE PCB BD EX /6	477,00
JP47737	SPARE PCB NE-A /2 Elektr.	157,00
JP47738	SPARE PCB NE-A /1	120,00
JP47739	SPARE PCB WCFIX 260 /2	84,00
JP47740	SPARE CAPACITOR 30µF/400V DB	29,80
JP47741	SPARE ENCLOSURE EXH-A/B	136,00
JP47742	SPARE CONTACTOR 230V DILM12-10	110,00
JP47743	SPARE CONTACTOR 230V DILM17-10	250,00
JP47744	SPARE PILOT LIGHT RED 220 V	42,00
JP47745	SPARE PILOT LIGHT WHITE 220 V	42,00
JP47746	SPARE MAGNET VALVE 230V 2-WAY	148,00
JP47747	UTD SPARE SIGNALLING CARD MK3-01	325,00
JP47749	SPARE MOTOR PROTECTION 12A ETA	134,00
JP47751	SPARE MOTOR PROTECTION 8A/30µF	152,00
JP47752	SPARE MOTOR PROTECTION 1,6-2,5 A, 1S, 1Ö	132,00
JP47753	SPARE MOTOR PROTECTION 2,5-4,0 A, 1S, 1Ö	132,00
JP47754	SPARE MOTOR PROTECTION 4,0-6,3 A, 1S, 1Ö	132,00
JP47755	SPARE MOTOR PROTECTION 6,3-10 A, 1S, 1Ö	132,00
JP47756	SPARE PCB NB1/4 LEVEL MODULE	169,00
JP47757	SPARE MOTOR CONTACTOR 230V DIL ER-22	75,00
JP47758	SPARE MOTOR CONTACTOR 230V SP B6-30-10-P	217,00
JP47759	SPARE MOTOR CONTACTOR C/W RETAINER	108,00
JP47760	SPARE DIGITAL TIMER D+W	457,00
JP47761	SPARE FUSE CARTRIDGE D01 6A 400V	19,20
JP47762	SPARE FUSE CARTRIDGE D01 10A 400V	12,00
JP47763	SPARE FUSE CARTRIDGE D02 35A 400V	19,30
JP47764	SPARE FUSE CARTRIDGE E27 2A 500V	19,40
JP47765	SPARE FUSE CARTRIDGE E27 16A 500V	20,00
JP47767	SPARE SGJU 2/3 PCB C/W PUSH BUTTON CAP	1668,00
JP47768	UTD SPARE DISCONNECTING BARRIER +/-24V A	123,00
JP47769	SPARE FUSE CARTRIDGE D02 25A 400V	17,50
JP47770	SPARE BATTERY CHARGER MK3	207,00
JP47771	SPARE SUBM. FLOAT SWITCH DRP, 20M	222,00
JP47772	SPARE SUBM. FLOAT SWITCH DRP, 30M	282,00
JP47773	SPARE PCB TB 1/6 TEMP. LIMITER MODULE	129,00

JP47774	SPARE PCB TEMPERATURE SENSOR MODULE TE	105,00
JP47775	SPARE THERMOSTAT 0-60°C 1NOC	101,00
JP47776	SPARE OVERCURRENTRELAIS Z00-10,6-10A	125,00
JP47777	SPARE OVERCURRENTRELAIS ZE-1,6 1-1,6A	125,00
JP47778	SPARE OVERCURRENTRELAIS ZE-2,4 1,6-2,4A	98,00
JP47779	SPARE OVERCURRENTRELAIS ZE- 4 2,4- 4 A	107,00
JP47780	SPARE OVERCURRENTRELAIS ZE- 6 4- 6 A	90,00
JP47781	SPARE OVERCURRENTRELAIS ZE- 9 6-9 A	105,00
JP47782	SPARE SELECTOR SWITCH 3 POSITIONS 1XUM	16,30
JP47783	SPARE SWITCH, 3 POSITIONS IP65-CAP	31,00
JP47784	SPARE TIMER RELAIS 24-240V AC MULTIF. 1W	201,00
JP47785	SPARE TIMER RELAIS 24-240V AC STAR-DELTA	185,00
JP47811	SPARE ADZ 25 HOUSING A + LEVEL CONTR.	731,00
JP47812	SPARE ADZ 25 HOUSING A	558,00
JP47813	SPARE ADZ 00 HOUSING A + LEVEL CONTR.	731,00
JP47814	SPARE ADZ 00 HOUSING A	558,00
JP47815	SPARE ADZ-E HOUSING A + LEVEL CONTR.	787,00
JP47816	SPARE ADZ-E HOUSING A	595,00
JP47817	SPARE ADZ 08/2ME HOUSING A + LEVEL C	787,00
JP47823	SPARE LEVEL CONTROLLER/1 C. 100+400S	257,00
JP47827	SPARE SLUICE VALVE DN40 PN16, ROW B	109,00
JP47828	SPARE VALVE FLAP R 80 RUBBERIZED	60,00
JP47829	SPARE CONDENSATE TANK K2	80,00
JP47830	SPARE LEVEL CONTROLLER BELLOWS C 400	266,00
JP47831	SPARE REFURBISHMENT KIT 260V	287,00
JP47832	SPARE PRESSURE PIPE PKS1200, DN 40	1091,00
JP47833	SPARE CABLE CONNECTOR 4-16MM RESIN	100,00
JP47837	SPARE CONTROL UNIT K2	109,00
JP47840	SPARE BASICLOGO-CONTROL UNIT ADZ46	1128,00
JP47841	SPARE PCB ADZ 610	502,00
JP47854	SPARE STATOR+HOUSING US 73 EX D	711,00
JP47855	SPARE STATOR+HOUSING US 73 EX W	689,00
JP47856	SPARE STATOR+HOUSING US 103 EX D	915,00
JP47857	SPARE STATOR+HOUSING US 103 EX W	820,00
JP47858	SPARE ROTORSHAFT US 73 EX D	162,00
JP47859	SPARE ROTORSHAFT US 73 EX W	139,00
JP47860	SPARE ROTORSHAFT US 103 EX W	218,00
JP47861	SPARE ROTORSHAFT US 103 EX W	284,00
JP47862	SPARE BEARING SET 11	49,00
JP47863	SPARE SCREW SET 6	20,70
JP47864	SPARE VOLUTE CASING US 73+ 103 EX	372,00
JP47930	SPARE BALL VALVE EXTENSION, REPLACEMENT	220,00
JP47931	SPARE PRESSURE OUTLET, REPLACEMENT	600,00
JP47932	SPARE ELAST.CONNECTION REPLACEMENT SET	197,00
JP47933	SPARE PRESSURE PIPE PKS-A 800, DN40	465,00
JP47960	SPARE CONNECTION SET INT. BAUFIX 100/4	253,00
JP47961	SPARE TANK BAUFIX 100	620,00
JP47966	SPARE SEALING COMPOUND COMPLI 300-1200	68,00
JP47967	SPARE O-RING COMPLI 500M, 1000M	42,00
JP47968	SPARE O-RING COMPLI 500M, 100M	44,00
JP48072	SPARE SWITCHCAM UNIT PLANCOFIX PLUS	114,00
JP48073	SPARE FIXING NUT PLANCOFIX	69,00
JP48074	SPARE MOTOR 025 PLANCOFIX	451,00
JP48075	SPARE MOTOR SEAL PLANCOFIX PLUS	29,80
JP48076	SPARE ACCESSORIES PLANCOFIX PLUS	125,00

JP48077	SPARE SEAL SET PLANCOFIX PLUS	29,80
JP48078	SPARE HYDRAULIC PLANCOFIX PLUS	71,00
JP48082	SPARE SHIM RINGS S D12X0,1 - 10 PCS	60,00
JP48083	SPARE SHIM RINGS S D12X0,2 - 10 PCS	60,00
JP48084	SPARE SHIM RINGS S D12X0,3 - 10 PCS	60,00
JP48085	SPARE SHIM RINGS S D18X0,1 - 10 PCS	24,30
JP48086	SPARE SHIM RINGS S D18X0,2 - 10 PCS	24,30
JP48087	SPARE SHIM RINGS S D18X0,3 - 10 PCS	24,30
JP48088	SPARE O-RINGS 10X2,5 - 10PC	12,60
JP48089	SPARE VALVE FLAP PLANCOFIX PLUS	62,00
JP48104	SPARE MOTOR DAMPER PLANCOFIX	69,00
JP48108	SPARE WEAR RING 13	412,00
JP48109	SPARE O-RINGS 38X3,5 - 10PC	13,90
JP48110	SPARE O-RINGS 47,22X3,54 - 10PC	23,90
JP48111	SPARE SHIM RINGS L D18X0,2 - 10 PCS	19,40
JP48112	SPARE SHIM RINGS L D25X0,1 - 10 PCS	19,40
JP48113	SPARE SHIM RINGS L D25X0,2 - 10 PCS	19,40
JP48114	SPARE SHIM RINGS L D12X0,2 - 10 PCS	19,40
JP48138	SPARE NON RETURN VALVE R40 COMPLI 500M	185,00
JP48139	SPARE NON RETURN VALVE R32 COMPLI 100M	89,00
JP48141	SPARE HOSE FASTENING SET, 2 PCS	10,90
JP48142	SPARE HOSE CONNECTOR SET, 2 PCS	12,30
JP48143	SPARE HOSE SET, 2 X 10M	43,00
JP48144	SPARE HOSE SET, 2 X 15M	67,00
JP48145	SPARE HOSE SET, 2 X 20M	93,00
JP48146	SPARE HIGHLOGO 1, DOOR-SET	712,00
JP48147	SPARE HIGHLOGO 2, DOOR-SET	761,00
JP48148	SPARE PRESSURE SENSOR SET, 10M	163,00
JP48157	SPARE CABLE 31C-15m	1779,00
JP48158	SPARE CABLE 31C-20m	2019,00
JP48159	SPARE CABLE 31C-25m	2259,00
JP48160	SPARE CABLE 31C-30m	2500,00
JP48224	SPARE MOTOR SEALS 5	41,00
JP48227	SPARE LEVEL CONTROLLER COMPLI, 15M	258,00
JP48231	SPARE HOSE CONNECTOR CONDENSATE PUMP	6,40
JP48232	SPARE SCREW AMTEC 10X30 - 20 PCS	25,80
JP48233	SPARE FLAT SEAL DN32 PN6	14,20
JP48234	SPARE ACTIVATED CARBON FILTER 5	13,90
JP48235	SPARE SET OF SEALS DN80 PN10	24,00
JP48236	SPARE OIL 1L- BOTTLE	27,10
JP48237	SPARE COUPLING UNIT DN40	470,00
JP48238	SPARE BALL REFLUX VALVE K1	13,90
JP48239	SPARE SET OF SEALS DN80 PN10, 2 PCS	46,00
JP48240	SPARE SEALING STRIP BAUFIX	21,50
JP48241	SPARE SET OF SEALS DN100 PN10	28,40
JP48242	SPARE SEAL COMPLI SERVICE LID	20,60
JP48244	SPARE FRAME C/W SEAL BAUFIX	174,00
JP48245	SPARE FRAME C/W SEAL BAUFIX	82,00
JP48246	SPARE RETAINER FLUTBOX	21,50
JP48247	SPARE FLOODBOX CAGE	69,00
JP48248	SPARE O-RING 212 X 7	20,00
JP48258	SPARE SAFETY CLIP SET, REPLACEMENT	67,00
JP48259	SPARE O-RING 45x5	31,00
JP48260	SPARE TIE BAR, REPLACEMENT	248,00
JP48261	SPARE SCREW SET 12	58,00

JP48304	SPARE FLOAT SWITCH DRY RUN PROT. 9,5M	162,00
JP48307	SPARE SM-MODULE SGJU5_ATEX	500,00
JP48308	SPARE TERMINAL RK2,5-4	16,90
JP48309	SPARE PUSH BUTTON M. 6,3 MM C/W SEAL CAP	24,20
JP48310	SPARE HINGE FOR CONTROL UNIT	23,10
JP48311	SPARE CONTACTOR 230V DIL EM 12-15 5,5KW	79,00
JP48312	SPARE OVERCURRENT RELAY ZE-12 9-12A	120,00
JP48313	SPARE PCB AD 910	705,00
JP48314	SPARE PCB AD 910 EX	776,00
JP48315	SPARE HANGER WITH TOP HAT RAIL	25,00
JP48316	SPARE SERIES TERMINAL 3L-DG-KL 2,5 QMM	12,60
JP48317	SPARE SERIES TERMINAL 2L-DG-KL 2,5 QMM	11,60
JP48318	SPARE SELECTOR WHEEL HIGHLOGO	13,30
JP48319	SPARE O-RING 198 X 4, 2 PC	24,70
JP48320	SPARE ELBOW 21X1/2	25,30
JP48321	SPARE SCREW AMTEC 6X18 - 5 PCS	22,40
JP48322	SPARE O-RING 86 X 6	31,00
JP48323	SPARE O-RING 105 X 15	25,80
JP48324	SPARE COVER	66,00
JP48325	SPARE O-RING 155 X 15	36,00
JP48326	SPARE O-RING 100 X 7	31,00
JP48339	SPARE ROTOR SHAFT D90-2/75 MULTIFREE	185,00
JP48340	SPARE ROTOR SHAFT D90-2/110 MULTIFREE	243,00
JP48341	SPARE ROTOR SHAFT D90-2/150 MULTIFREE	350,00
JP48342	SPARE ROTOR SHAFT D90-4/75 MULTIFREE	207,00
JP48343	SPARE ROTOR SHAFT D90-4/110 MULTIFREE	266,00
JP48344	SPARE ROTOR SHAFT D90-4/150 MULTIFREE	365,00
JP48346	SPARE ROTOR SHAFT D112-2/140 MF	622,00
JP48347	SPARE ROTOR SHAFT D112-2/200 MULTIFREE	950,00
JP48348	SPARE ROTOR SHAFT D112-4/110 MULTIFREE	620,00
JP48349	SPARE ROTOR SHAFT D112-4/140 MULTIFREE	647,00
JP48350	SPARE ROTOR SHAFT D112-4/200	973,00
JP48351	SPARE VORTEX IMPELLER 10/2 AW1	145,00
JP48352	SPARE VORTEX IMPELLER 15/2 AW1	147,00
JP48353	SPARE VORTEX IMPELLER 25/2 AW1	157,00
JP48354	SPARE VORTEX IMPELLER 35/2 AW1	175,00
JP48355	SPARE VORTEX IMPELLER 15/4 AW2	297,00
JP48356	SPARE VORTEX IMPELLER 25/4 AW2	347,00
JP48357	SPARE VORTEX IMPELLER 35/4 AW2	365,00
JP48358	SPARE VORTEX IMPELLER 45/4 AW2	391,00
JP48359	SPARE VORTEX IMPELLER 25/2 BW1	193,00
JP48360	SPARE VORTEX IMPELLER 35/2 BW1	203,00
JP48361	SPARE VORTEX IMPELLER 45/2	595,00
JP48362	SPARE VORTEX IMPELLER 10/4 CW1	375,00
JP48363	SPARE VORTEX IMPELLER 15/4 BW1+CW1	254,00
JP48364	SPARE VORTEX IMPELLER 25/4 BW1 + CW1	273,00
JP48365	SPARE VORTEX IMPELLER 35/4 BW1 + CW1	317,00
JP48366	SPARE VORTEX IMPELLER 45/4 BW2 + CW2	595,00
JP48367	SPARE VORTEX IMPELLER 75/2 BW1 + CW1	915,00
JP48368	SPARE VORTEX IMPELLER 100/2 BW1 + CW1	950,00
JP48369	SPARE VORTEX IMPELLER 55/4 BW2	682,00
JP48370	SPARE VORTEX IMPELLER 75/4 BW2	915,00
JP48371	SPARE VORTEX IMPELLER 100/4 BW2	950,00
JP48372	SPARE VORTEX IMPELLER 55/4 CW2	647,00
JP48373	SPARE VORTEX IMPELLER 75/4 CW2	993,00

JP48374	SPARE VORTEX IMPELLER 100/4 CW2	1030,00
JP48375	SPARE VORTEX IMPELLER SSR	627,00
JP48376	SPARE STATOR C/W HOUSING D90-2/150	1320,00
JP48377	SPARE STATOR C/W HOUSING D90-4/150	1399,00
JP48378	SPARE BEARING SET 12	193,00
JP48379	SPARE BEARING COVER 4	131,00
JP48380	SPARE SHAFT COVER 4	58,00
JP48381	SPARE MECHANICAL SEAL 4	189,00
JP48384	SPARE BEARING HOUSING 10	661,00
JP48386	SPARE SET OF SEALS 12	58,00
JP48387	SPARE SCREW SET 13	25,80
JP48388	SPARE BEARING HOUSING 11	865,00
JP48405	SPARE VOLUTE CASING 45/2 M TANDEM	571,00
JP48453	SPARE GUIDE RAIL TUBE PKS-B 800-D32	84,00
JP48454	SPARE TIE BAR PKS-B 800-D32	552,00
JP48455	SPARE INSTALLATION SET SKS-B800 DN32	333,00
JP48456	SPARE INSTALLATION SET SKS-B800 DN50	716,00
JP48457	SPARE OUTLET SET SKS-B800 DN32	300,00
JP48458	SPARE OUTLET SET SKS-B800 DN50	506,00
JP48459	SPARE VALVE HANDLE EXTENSION SKS-B800	220,00
JP48460	SPARE HOSE ELBOW DN32	66,00
JP48461	SPARE HOSE ELBOW DN50	105,00
JP48462	SPARE GUIDE RAIL SKS-B 800-D32	243,00
JP48463	SPARE GUIDE RAIL SKS-B 800-D50	157,00
JP48464	SPARE KT RETAINER SKS-B800 DN32+D50	181,00
JP48465	SPARE SEAL PRESSURE OUTLET SKS-B800 DN32	91,00
JP48466	SPARE SEAL PRESSURE OUTLET SKS-B800 DN50	91,00
JP48467	SPARE LEVEL CONTR. RETAINER SKS-B800	63,00
JP48490	SPARE MOTOR PROTECTION 4A	134,00
JP48491	SPARE PCB AD 23 EX /4	486,00
JP48492	SPARE OVERCURRENT RELAIS ZB 12-10, 6-10A	145,00
JP48507	SPARE PUMP UNIT WCFIX 260	444,00
JP48512	SPARE PUMP UNIT WCFIX 260V	444,00
JP48526	SPARE BASICLOGO CONTROL UNIT AD 69ECP	1299,00
JP48527	SPARE PCB AD 69ECP	631,00
JP48539	SPARE ACCESSORIES U5K(S)	28,40
JP48540	SPARE ACCESSORIES HEBEFIX /3	91,00
JP48541	UTD SPARE ACCESSORIES COMPLI	187,00
JP48542	SPARE ACCESSORIES COMPLI 300	235,00
JP48543	SPARE ACCESSORIES GR 35	51,00
JP48545	SPARE PUMP UNIT WCFIX 260V /02	444,00
JP48546	SPARE PUMP UNIT WCFIX 260V /03	395,00
JP48547	SPARE PUMP UNIT + PCB WCFIX 260V /03	649,00
JP48548	SPARE CONVERSION SET WCFIX 260	287,00
JP48549	SPARE CONVERSION SET WCFIX 260 A	287,00
JP48550	SPARE COVER PLATE COMPLI	128,00
JP48562	SPARE PRESSURE PIPE UNIT MULTICUT	426,00
JP48563	SPARE PRESSURE PIPE UNIT MULTICUT 08	426,00
JP48564	SPARE PRESSURE PIPE UNIT FOR REPLACEMENT	426,00
JP48565	SPARE PRESSURE PIPE UNIT D MULTICUT	426,00
JP48591	SPARE VOLUTE CASING AW2	642,00
JP48592	SPARE VOLUTE CASING BW2	1258,00
JP48593	SPARE VOLUTE CASING CW3	1665,00
JP48625	SPARE TANK SEAL SET PKS 800-32	23,10
JP48626	SPARE CONTROL UNIT BD 610 ECP, C1008/2ME	1951,00

JP48684	SPARE UC 10/4 BWE, 15M CABLE VERS. 02	1818,00
JP48685	SPARE CABLE GLAND COMPLI (5G1,5) -15M	424,00
JP48707	SPARE TANK BAUFIX 200-32	1116,00
JP48708	SPARE TANK BAUFIX 200-50	1116,00
JP48709	SPARE TANK HEBEFIX 200-32	1116,00
JP48710	SPARE TANK HEBEFIX 200-50	1116,00
JP48711	SPARE TANK VACUBOX UNDER FLOOR	1116,00
JP48712	SPARE TANK VACUBOX ABOVE FLOOR	1116,00
JP48713	SPARE LID HEBEFIX 200	208,00
JP48714	SPARE LID VACUBOX	208,00
JP48716	SPARE NON RETURN VALVE 200-32	91,00
JP48717	SPARE PIPEWORK 200-50	247,00
JP48718	SPARE NON RETURN VALVE 200-50	107,00
JP48719	SPARE LID SEAL	46,00
JP48720	SPARE BUOYANCY PROTECTION	63,00
JP48721	SPARE CONNECTION SET DN 32	171,00
JP48722	SPARE CONNECTION SET DN 50	236,00
JP48739	SPARE PIPEWORK 200-32	143,00
JP48741	SPARE PIPEWORK PKS-A 1200-D40	714,00
JP48742	SPARE PIPEWORK PKS-A 1200-40	361,00
JP48743	SPARE TIE BAR PKS-A 1200	612,00
JP48744	SPARE HANDLE EXTENSION PKS-A 1200	84,00
JP48747	SPARE THRUST PIECE WCFIX 260	53,00
JP48780	SPARE O-RING 142X6	22,50
JP48782	SPARE SEAL BUSHING DKS	113,00
JP48783	SPARE CONVERSION SET DKS, VERS. 00 TO 02	240,00
JP48795	SPARE COVER C/W THREAD 1 1/2"	59,00
JP48798	SPARE OIL FOR JUN-AIR COMPRESSOR 0,5L	93,00
JP48800	SPARE COMPRESSOR SH	2859,00
JP48801	SPARE COMPRESSOR RACK SH FROM 2017	157,00
JP48824	SPARE PUMP UC 15/4 BW /2	1478,00
JP48825	SPARE PUMP UC 25/4 BW /2	1478,00
JP48826	SPARE PUMP UC 25/2 BW /3	2664,00
JP48827	SPARE PUMP UC 35/2 BW /3	2854,00
JP48828	SPARE ROTOR SHAFT 10-25/4 BW	222,00
JP48829	UTD SPARE VORTEX IMPELLER 10/4 BW	67,00
JP48830	SPARE VORTEX IMPELLER 15/4 BW	123,00
JP48831	SPARE VORTEX IMPELLER 25/4 BW	147,00
JP48835	SPARE FRAME FOR BAUFIX 200-50 COVER	348,00
JP48836	SPARE COVER BAUFIX 200-50	362,00
JP48837	SPARE SEAL FOR BAUFIX 200-50 COVER	45,00
JP48840	SPARE AIR TUBE SET, 2X 30M	139,00
JP48852	SPARE BUZZER 12VDC C/W LEADS	16,40
JP48853	SPARE SERVICE COVER R100 G/3+R101/2	105,00
JP48854	SPARE SERVICE COVER R80 G/1+R80/3	71,00
JP48855	SPARE SEAL SET DN32 PN6	36,00
JP48857	SPARE PRESSURE PIPE DN32	253,00
JP48858	SPARE PRESSURE PIPE DN40	283,00
JP48859	SPARE PRESSURE PIPE PKS-D 750LG	333,00
JP48860	SPARE PRESSURE PIPE PKS-D 1250LG	427,00
JP48861	SPARE O-RING K2	20,40
JP48870	SPARE CONTROL UNIT HEBEFIX PLUS UK	181,00
JP48871	SPARE REDUCER DN150/DN100	46,00
JP48873	SPARE SUBM. BALL CONTACT SWITCH DRP, 15M	193,00
JP48879	SPARE CAPACITOR 35µF	39,00

JP48880	SPARE MOTOR CONTACTOR 3, UV SERIES	104,00
JP48881	SPARE FLOAT SWITCH UV	106,00
JP48882	SPARE PLUG UV	38,00
JP48883	SPARE CABLE 51A - 10M, UV SERIES	238,00
JP48884	SPARE CABLE 51C - 10M, UV SERIES	246,00
JP48885	SPARE DOUBLE JACKET UV TYP 100	296,00
JP48886	SPARE DOUBLE JACKET UV TYP 120	296,00
JP48887	SPARE PLUG UV PRESSURE OUTLET	43,00
JP48888	SPARE MOTOR + HOUSING D80-2/100	502,00
JP48889	SPARE MOTOR + HOUSING D80-2/120	597,00
JP48890	SPARE MOTOR + HOUSING E80-2/100	486,00
JP48891	SPARE PLUG UV 1 HOLE	81,00
JP48892	SPARE PLUG UV 2 HOLE	81,00
JP48893	SPARE BEARING SET 13, UV SERIES	89,00
JP48894	SPARE ROTOR SHAFT UV 20...25	215,00
JP48895	SPARE ROTOR SHAFT UV 35	254,00
JP48896	SPARE PCB BOARD UV D	94,00
JP48897	SPARE PCB BOARD UV 620-1	132,00
JP48898	SPARE SET OF SEALS 13, UV SERIES	81,00
JP48899	SPARE SCREW SET 13, UV SERIES	57,00
JP48900	SPARE COVER UV 600	74,00
JP48901	SPARE BEARING FLANGE UV 600	282,00
JP48902	SPARE MECH. SEAL SET 10, UV SERIES	152,00
JP48903	SPARE SEAL COVER UV SERIES	63,00
JP48904	SPARE OIL-SCREW UV	23,90
JP48905	SPARE IMPELLER UV 620	239,00
JP48906	SPARE IMPELLER UV 625	239,00
JP48907	SPARE IMPELLER UV 635	239,00
JP48908	SPARE VOLUTE CASING COVER UV600	140,00
JP48914	SPARE STRAINER BASE UV600	101,00
JP48921	SPARE BLIND FLANGE	36,00
JP48972	SPARE PRESSURE PIPE PKS-A 800, DN 40	502,00
JP48979	SPARE FLOAT SWITCH AG/AW3 - 3M	74,00
JP48980	SPARE FLOAT SWITCH AG/AW10 - 9,5M	129,00
JP48998	SPARE ROTARY LEVEL CONTROLLER 15M CABLE	537,00
JP49001	SPARE ACCESSORIES UC BW REPLACEMENT	31,00
JP49055	SPARE CABLE 31B1-15M	1333,00
JP49056	SPARE CABLE 31B1-20M	1528,00
JP49057	SPARE CABLE 31B1-25M	1723,00
JP49058	SPARE CABLE 31B1-30M	1920,00
JP49064	SPARE RETAINER SUBM. FLOAT SWITCH	63,00
JP49065	SPARE RETAINER FOR PRESSURE SENSOR	101,00
JP49066	SPARE COUPLING CLAW GR32	60,00
JP49067	SPARE LM/2 MODUL	125,00
JP49068	SPARE O-RING 36 x 4	25,80
JP49069	SPARE SUBM. FLOAT SWITCH 3,0 M CABLE	112,00
JP49070	SPARE SECURITY LEVER GR32	42,00
JP49071	SPARE ACCESSORIES WCFIX 260	106,00
JP49128	SPARE RETAINER SPARE GR32	57,00
JP49249	SPARE SCREW SET 14	57,00
JP49250	SPARE ROTOR SHAFT UV305	203,00
JP49251	SPARE ROTOR SHAFT UV310+315	217,00
JP49252	SPARE COVER UV300	74,00
JP49253	SPARE DOUBLE JACKET UV300	259,00
JP49254	SPARE STATOR + HOUSING E80-2/50	443,00

JP49255	SPARE STATOR + HOUSING E80-2/70	470,00
JP49256	SPARE STATOR + HOUSING D80-2/50	456,00
JP49257	SPARE STATOR + HOUSING D80-2/70	475,00
JP49258	SPARE CABLE GLAND 52-10 M	140,00
JP49259	SPARE CABLE GLAND 53-10 M	162,00
JP49260	SPARE BEARING HOUSING FLANGE UV300	282,00
JP49261	SPARE IMPELLER UV305	112,00
JP49262	SPARE IMPELLER UV310	112,00
JP49263	SPARE IMPELLER UV315	186,00
JP49264	SPARE STRAINER BASE UV300	113,00
JP49265	SPARE STRAINER BASE UV300	60,00
JP49266	SPARE CAPACITOR UV305	39,00
JP49267	SPARE CAPACITOR UV310+315	44,00
JP49275	SPARE ACCESSORIES BAUFIX 100	146,00
JP49276	SPARE HOSE CLAMP 40-60	36,00
JP49571	SPARE ELECTRODE DKG, 20 M CABLE	328,00
JP49572	SPARE ELECTRODE DKG, 30 M CABLE	399,00
JP49703	SPARE IMPELLER U3KS HEBEFIX EXTRA	71,00
JP50038	SPARE ELBOW 1 1/4 ", AG/IG	25,30
JP50059	SPARE O-RING SET K50	36,00
JP50060	SPARE O-RING SET K40	36,00
JP50061	SPARE O-RING SET K40 PLASTIC	36,00
JP50062	SPARE O-RING SET R80, R80G, K80	31,00
JP50063	SPARE O-RING SET R101, R101G	31,00
JP50064	SPARE STRAINER BASE U3, VERS. 01	44,00
JP50065	SPARE IMPELLER U6, VERS. 01	59,00
JP50066	SPARE VOLUTE CASING U6, VERS. 01	68,00
JP50067	SPARE COVER U6, VERS. 01	41,00
JP50068	SPARE BULB 5-7W/230V, WARNING LIGHT	33,00
JP50069	SPARE RETAINER FOR PRESSURE SENSORS	63,00
JP50070	SPARE AUXILLIARY RELAY DIL M32-XHI22	44,00
JP50071	SPARE MODULE NZ 1/3	193,00
JP50072	SPARE TIE-BAR PKS-A 800-D40	552,00
JP50073	SPARE CONNECTION SEAL DN100	59,00
JP50161	SPARE CABLE 61A-15M	357,00
JP50162	SPARE UC 10/4 BW TANK PUMP /2 15M	1635,00
JP50163	SPARE UC 15/4 BW TANK PUMP /2 15M	1635,00
JP50164	SPARE UC 25/4 BW TANK PUMP /2 15M	1635,00
JP50175	SPARE PCB HIGHLOGO 1	522,00
JP50176	SPARE PCB HIGHLOGO 2	578,00
JP50180	SPARE PCBA HEBEFIX PLUS+EXTRA	123,00
JP50181	SPARE BALL + O-RING KE40 P	80,00
JP50182	SPARE COVER HEBEFIX MINI	54,00
JP50183	SPARE PCB HEBEFIX MINI	90,00
JP50184	SPARE PRESSURE OUTLET HEBEFIX MINI	52,00
JP50185	SPARE OUTLET ELBOW HEBEFIX MINI	62,00
JP50186	SPARE TANK HEBEFIX MINI	267,00
JP50187	SPARE HIGHLOGO RTC + USV MODUL	301,00
JP50188	SPARE ELBOW HEBEFIX MINI	67,00
JP50189	SPARE MAINTENANCE COVER HEBEFIX MINI	48,00
JP50190	SPARE HIGHLOGO GSM MODEM	575,00
JP50191	SPARE GSM AERIAL	139,00
JP50192	SPARE IMPELLER HEBEFIX MINI	49,00
JP50193	SPARE MOTOR UNIT HEBEFIX MINI	226,00
JP50194	SPARE GRID PLANCOFIX LINE	162,00

JP50195	SPARE SWITCH CAM UNIT HEBEFIX MINI	125,00
JP50196	SPARE CABLE HEBEFIX MINI	43,00
JP50197	SPARE CAPACITOR HEBEFIX MINI	38,00
JP50198	SPARE O-RING SET HEBEFIX MINI	33,00
JP50199	SPARE GRID PLANCOFIX LINE	140,00
JP50200	SPARE ACCESSORIES HEBEFIX MINI	116,00
JP50201	SPARE PLUG HEBEFIX MINI	29,80
JP50202	SPARE VENTILATION HEBEFIX MINI	37,00
JP50209	SPARE ACCESSORIES PLANCOFIX LINE	125,00
JP50214	SPARE FLUSHING CONNECTOR KE 250	206,00
JP50215	SPARE STOP VALVE DN40 PN16 ROW B-80 LG	186,00
JP50231	SPARE SET OF SEALS DN 32 PN 6	28,40
JP50250	SPARE SEAL FOR COMPLI LEVEL CONTROLLER	29,80
JP50251	SPARE GRID LIFTING TOOL	29,80
JP50252	SPARE NON RETURN VALVE R80 PKS-A800	597,00
JP50253	SPARE CONTACTOR 230V DILM17-10	128,00
JP50254	SPARE CONTACTOR 230V DILM32-10	218,00
JP50255	SPARE OVERCURRENT RELAIS ZB32-16 10-16A	128,00
JP50256	SPARE OVERCURRENT RELAIS ZB32-24	128,00
JP50257	SPARE OVERCURRENT RELAIS ZB32-32	153,00
JP50258	SPARE TANK VENTILATION HEBEFIX	43,00
JP50259	SPARE LID HEBEFIX	84,00
JP50260	SPARE LID SEAL HEBEFIX	43,00
JP50261	SPARE TANK HEBEFIX	142,00
JP50262	SPARE OUTLET ELBOW HEBEFIX	84,00
JP50263	SPARE PCB UV620-1S	176,00
JP50264	SPARE PCB UV305-1+S	136,00
JP50265	SPARE PCB UV310/315-1+S	136,00
JP50283	SPARE CONDENSATE TANK K1	59,00
JP50284	SPARE CONDENSATE RETAINER K1	49,00
JP50285	SPARE MICRO SWITCH K1	38,00
JP50286	SPARE IMPELLER K1	29,80
JP50287	SPARE HYDRAULIC O-RING K1	27,10
JP50288	SPARE TANK FEET K1	29,80
JP50289	SPARE SCREW SET K1	28,40
JP50290	SPARE SCHUKO MOTOR PROTECTIVE PLUG	129,00
JP50291	SPARE PUMP SUSPENSION COMPL.	253,00
JP50292	SPARE PUMP SUSPENSION	52,00
JP50295	SPARE PIPEWORK HEBEFIX V	59,00
JP50296	SPARE VENTILATION SCREEN HEBEFIX V	12,50
JP50297	SPARE LID SEAL HEBEFIX V	39,00
JP50301	SPARE VIBRATION DAMPER BREEZE SH	46,00
JP50305	SPARE ACCESSORIES HEBEFIX	80,00
JP50306	SPARE ACCESSORIES REPLACEMENT SET 32	131,00
JP50309	SPARE CUTTING ROTOR 75+76/2 M	167,00
JP50316	SPARE LID - 32 C/W SEAL	43,00
JP50317	SPARE LID WITH THREAD KE40 P	45,00
JP50320	SPARE VORTEX IMPELLER UC15/4 BW	123,00
JP50321	SPARE VORTEX IMPELLER UC25/4 BW	147,00
JP50322	SPARE ROTOR SHAFT UC15-25/4 BW	246,00
JP50323	SPARE O-RING 21x2	9,50
JP50324	SPARE CUTTER PLATE	126,00
JP50326	SPARE CUTTER 08-20/2M	167,00
JP50327	SPARE CUTTER 25-45/2M	167,00
JP50328	SPARE MOTOR UNIT COMPLI 310 E	949,00

JP50329	SPARE TANK COMPLI 310E	1215,00
JP50330	SPARE CABLE UC 300 E CONI	139,00
JP50331	SPARE LEVEL CONTROLLER COMPLI 300 E CONI	297,00
JP50332	SPARE FILTER 1/4" BREEZE SH	95,00
JP50333	SPARE REDUCING BUSH PLANCOFIX	29,80
JP50379	SPARE STOP VALVE DN50 PN16 STAINLESS ST.	271,00
JP50434	SPARE PRESSURE SEAL GR50/0, 5 PCS	60,00
JP50435	SPARE DOOR FOR CABINET SIZE A	186,00
JP50436	SPARE LOCK RECEIVER FOR CABINET SIZE A	131,00
JP50437	SPARE LOCK RECEIVER FOR CABINET SIZE A	131,00
JP50439	SPARE DISCONNECTING BARRIER JP46797	125,00
JP50445	SPARE FLANGE CONNECTION SET 1 1/4" DN32	86,00
JP50447	SPARE UC STATOR+HOUSING D90-4/75D	894,00
JP50448	SPARE UC STATOR+HOUSING D90-4/75C	921,00
JP50449	SPARE O-RING SET 14 (UC 4 POLE)	33,00
JP50450	SPARE SCREW SET 14 (UC 4 POLE)	25,10
JP50467	SPARE DKS COMPACT	232,00
JP50468	SPARE DKS COMPACT, 15M	251,00
JP50469	SPARE UC 10/4 BW /2 TANK PUMP	1399,00
JP50470	SPARE UC 10/4 BWE /3 TANK PUMP	1478,00
JP50471	SPARE PUMP VENTILATION COMPLI 1100	55,00
JP50472	SPARE INLET COMPLI 400	118,00
JP50473	SPARE FLOATING PROOF SET COMPLI	63,00
JP50474	SPARE COMPLI TANK 400 /10	1024,00
JP50476	SPARE MOUNTING RING NRV COMPLI 400	166,00
JP50477	SPARE PUMP ADAPTOR FLANGE COMPLI 400	221,00
JP50478	SPARE ADAPTOR RING DN100/DN80	82,00
JP50479	SPARE SEAL LEVEL CONTROLLER	36,00
JP50480	SPARE SEAL SET 14 (HYDRAULIK C400)	51,00
JP50481	SPARE SEALS 15 (compli 400 outlet)	43,00
JP50484	SPARE PUMP 12/2	655,00
JP50485	SPARE CABLE 61A-4M	153,00
JP50486	SPARE CABLE 61-4M	142,00
JP50487	SPARE CABLE 61-15M	231,00
JP50488	SPARE HOUSING & WINDING D90-4/50B	820,00
JP50489	SPARE PUMP RECEIVER BIOX 400/12	199,00
JP50491	SPARE BASICLOGO PANEL AD 00R	912,00
JP50492	SPARE BASICLOGO PANEL AD 25R	1068,00
JP50493	SPARE BASICLOGO PANEL AD 46R	1068,00
JP50494	SPARE BASICLOGO PANEL AD 610R	1068,00
JP50495	SPARE BASICLOGO PANEL AD 69ECR	1068,00
JP50496	SPARE BASICLOGO PANEL AD 69MECR	3073,00
JP50497	SPARE PCBA AD 00 /0	319,00
JP50498	SPARE PCBA AD 25/0	447,00
JP50499	SPARE PCBA AD 46/0	447,00
JP50500	SPARE PCBA AD 610/0	451,00
JP50501	SPARE PCBA AD 69EC /0	456,00
JP50502	SPARE DKS COMPACT COMPLI 100	232,00
JP50503	SPARE CONTROL PANEL BASIC LOGO BD 610ER	1278,00
JP50504	SPARE CONTROL PANEL BASIC LOGO BD 610ECR	1278,00
JP50505	SPARE CONTROL PANEL BASIC LOGO BD 25R	1278,00
JP50506	SPARE CONTROL PANEL BASIC LOGO BD 46R	1278,00
JP50507	SPARE CONTROL PANEL BASIC LOGO BD 610R	1535,00
JP50508	SPARE CONTROL UNIT BASICLOGO BD 610MECR	4095,00
JP50509	SPARE CONTROL UNIT HIGHLOGO 2-610ECP	2404,00

JP50510	SPARE CONTROL UNIT HIGHLOGO 2-25P	2287,00
JP50511	SPARE CONTROL UNIT HIGHLOGO 2-46P	2287,00
JP50512	SPARE CONTROL UNIT HIGHLOGO 2-610P	2287,00
JP50513	SAPRE CONTROL UNIT HIGHLOGO 2-610PD	5190,00
JP50514	SPARE CONTROL UNIT HIGHLOGO 5-1016P	5902,00
JP50515	SPARE CONTROL UNIT HIGHLOGO 5-1620P	6234,00
JP50516	SPARE CONTROL UNIT HIGHLOGO 5-2532P	7293,00
JP50517	SPARE ACCESSORIES TANK PUMP REPLACEMENT	42,00
JP50518	SPARE CONTACTOR DILMT9	91,00
JP50519	SPARE AUXILIARY SWITCH 11 DILT-XHI11	35,00
JP50520	SPARE CAPACITOR S2 30uF/425V	48,00
JP50521	SPARE CAPACITOR S2 20uF/450V	51,00
JP50522	SPARE RESISTOR 47K 3W (70GRAD C) ±5%	64,00
JP50523	SPARE TIMER RELAIS 1W	166,00
JP50524	SPARE PCBA AD 69MECR	695,00
JP50531	SPARE MICROSWITCH 3	33,00
JP50532	SPARE MICROSWITCH 4	33,00
JP50535	SPARE CAPACITOR 6µF, S2	38,00
JP50536	SPARE CABLE GLAND UV3S, 4M	112,00
JP50537	SPARE CABLE GLAND UV3S, 10M	172,00
JP50538	SPARE CABLE GLAND UV3, 10M	112,00
JP50539	SPARE CABLE GLAND UV3SF, 10M	172,00
JP50540	SPARE CABLE GLAND U3KS, 4M	112,00
JP50541	SPARE CABLE GLAND U3KS, 10M	112,00
JP50542	SPARE CABLE GLAND U3KS, 10M	158,00
JP50543	SPARE CABLE GLAND U3KS SPECIAL, 4M	129,00
JP50544	SPARE CABLE GLAND U3KS SPECIAL, 10M	172,00
JP50545	SPARE CABLE GLAND U3K SPECIAL, 10M	172,00
JP50548	SPARE VOLUTE CASING UV3	114,00
JP50549	SPARE MOTOR HOUSING UV3	68,00
JP50550	SPARE IMPELLER U3-03 / UV3	42,00
JP50551	SPARE IMPELLER U3 SPECIAL-03	34,00
JP50552	SPARE MOTOR UNIT U3-03	275,00
JP50553	SPARE MOTOR UNIT U3 SPECIAL-03	299,00
JP50554	SPARE MOTOR UNIT UV3	288,00
JP50555	SPARE VOLUTE CASING U3-03	58,00
JP50556	SPARE VOLUTE CASING UV3	77,00
JP50557	SPARE SCREW SET 13	23,10
JP50558	SPARE SCREW SET 14	27,10
JP50559	SPARE SEAL SET 14	12,00
JP50560	SPARE SET OF SEALS 15	37,00
JP50561	SPARE FLUSHING PLUG	27,80
JP50563	SPARE FLOAT 5 (AGMA UV3)	93,00
JP50566	SPARE DUPLEX NON RETURN VALVE COMPLI	236,00
JP50568	SPARE CONTROL UNIT EASYLOGO 2-00 E	1628,00
JP50571	SPARE SEALING MAT OF FIBRE CONNECT	187,00
JP50572	SPARE SERVICE LID CONNECT	58,00
JP50573	SPARE SEAL SET CONNECT	27,30
JP50574	SPARE HYDRAULIC CONNECT	94,00
JP50576	SPARE FLOAT CONNECT	90,00
JP50577	SPARE TANK CONNECT	336,00
JP50578	SPARE POWER CORD CONNECT	67,00
JP50579	SPARE ELECTRONIC CONNECT	146,00
JP50584	SPARE UC 10/4 BWE TANK PUMP /3 15M	1890,00
JP50605	SPARE CABLE GLAND 31-20M	771,00

JP50618	SPARE MOTOR RECEIVER HEBEFIX MINI	54,00
JP50619	SPARE SET UC15/4 BW MK.1 TO MK.2	333,00
JP50620	SPARE SET UC25/4 BW MK.1 TO MK.2	378,00
JP50621	SPARE SINGLE CHANNEL IMPELLER 10/2 A1	452,00
JP50622	SPARE SINGLE CHANNEL IMPELLER 15/2 A1	477,00
JP50623	SPARE SINGLE CHANNEL IMPELLER 25/2 A1	401,00
JP50624	SPARE SINGLE CHANNEL IMPELLER 35/2 A1	447,00
JP50625	SPARE SINGLE CHANNEL IMPELLER 25/2 B1	436,00
JP50626	SPARE SINGLE CHANNEL IMPELLER 35/2 B2	444,00
JP50627	SPARE SINGLE CHANNEL IMPELLER 10/4 B1	478,00
JP50628	SPARE SINGLE CHANNEL IMPELLER 15/4 B3	478,00
JP50629	SPARE SINGLE CHANNEL IMPELLER 25/4 B4	811,00
JP50630	SPARE SINGLE CHANNEL IMPELLER 35/4 B4	821,00
JP50631	SPARE SINGLE CHANNEL IMPELLER 25/4 C1	968,00
JP50632	SPARE SINGLE CHANNEL IMPELLER 35/4 C1	948,00
JP50633	SPARE IMPELLER FIXATION 10-35	57,00
JP50634	SPARE O-RING 25x2 - 10pcs.	22,10
JP50678	SPARE CLAMPING WEDGE PLANCOFIX	6,90
JP50679	TEMPLATE FINISHED GOODS INHOUSE-PRODUCT	10,80
JP50681	SPARE UC 75/4 C5/2 PUMP-SPECIAL 60HZ	12314,00
JP50685	SPARE 3 ACTIVATED CARBON FILTER D70x10	37,00
JP50693	SPARE PUMP FLANGE COMPLI 400 2POL	221,00
JP50694	SPARE U3KS-02 FOR HEBEFIX V	373,00
JP50695	SPARE LEVEL CONTROL WITH END SUPP. 15M	548,00
JP50778	SPARE ACCESSORIES COMPLI	191,00
JP50779	SPARE PART UPPER HOUSING K1 GREEN	49,00
JP50780	SPARE PART UPPER HOUSING K1 IRONGREY	49,00
JP50781	SPARE PRESSURE PIPE PKS 800, DN 80	1714,00
JP50784	SPARE PART ELECTRONIC EASYLOGO 2-00 E	401,00
JP50785	SPARE PART COMPONENT BEARER K1	46,00
JP50786	SPARE PRESSURE PIPE PKS-A 1200, DN 80	1967,00
JP50787	SPARE BASICLOGO CONTROL UNIT AD 00R GB	1116,00
JP50788	SPARE BASICLOGO CONTROL UNIT AD 25R GB	1465,00
JP50789	SPARE BASICLOGO CONTROL UNIT AD 46R GB	1465,00
JP50790	SPARE BASICLOGO CONTROL UNIT AD 610R GB	1465,00
JP50791	SPARE BASICLOGO CONTROL UNIT AD 69ECR GB	1465,00
JP50792	SPARE BASICLOGO CONTROL UNIT AD69MECR GB	3622,00
JP50793	SPARE BASICLOGO CONTROL UNIT BD 25R GB	1583,00
JP50794	SPARE BASICLOGO CONTROL UNIT BD 46R GB	1583,00
JP50795	SPARE BASICLOGO CONTROL UNIT BD 610R GB	1583,00
JP50796	SPARE CONTROL UNIT BD 610ECR GB	1583,00
JP50797	SPARE CONTROL UNIT BD 610MECR GB	4382,00
JP50798	SPARE CONTROL UNIT HIGHLOGO 2-25P GB	2594,00
JP50799	SPARE CONTROL UNIT HIGHLOGO 2-46P GB	2594,00
JP50800	SPARE CONTROL UNIT HIGHLOGO 2-610ECP GB	2594,00
JP50801	SPARE CONTROL UNIT HIGHLOGO 2-610P GB	2594,00
JP50802	SPARE CONTROL UNIT HIGHLOGO 2-610PD GB	5190,00
JP50803	SPARE CONTROL UNIT HIGHLOGO 5-1016P GB	5902,00
JP50804	SPARE CONTROL UNIT HIGHLOGO 5-1620P GB	6234,00
JP50805	SPARE CONTROL UNIT HIGHLOGO 5-2532P GB	7293,00
JP50806	SPARE OIL SIMER, 1L	34,00
JP50808	SPARE COUPLING PIPE PKS800 DN65 WFL	1476,00
JP50809	SPARE COUPLING PIPE PKS1200 DN65 WFL	1497,00
JP50810	SPARE UC 10/4 BWE /3 W/O CABLE	1428,00
JP50811	ERSATZ UC 10/4 BW /2 W/O CABLE.	1349,00

JP50812	ERSATZ UC 15/4 BW /2 W/O CABLE	1428,00
JP50828	SPARE GSM ARIAL 10M SMA ST.	235,00
JP50829	SPARE GSM ARIAL 20M SMA ST.	391,00
JP50862	SPARE FOOT SET UV300/600 KPL	305,00
JP55048	SPARE FLEX HOSE BREEZE G1/4 370MM	230,00
JP55990	SPARE COUPLING RECEIVER DN80	213,00
JP55991	SPARE TIE BAR PKS-A 800 -80	561,00
ZBR39590	SPARE HANDLE KIT	26,80
ZBR39600	SPARE HOSE ADAPTER	15,40
ZBR39610	SPARE SIMER 4+5 CABLE (D)	72,00
ZBR39620	SPARE SIMER 4+5 CABLE (CH)	72,00
ZBR39640	SPARE SIMER STRAINER	13,60
ZBR39660	SPARE POWER CORD SIMER & (D)	70,00
ZBR39670	SPARE POWER CORD SIMER & (CH)	72,00
ZBR39680	SPARE POWER CORD SIMER & (UK)	72,00
ZBR39690	SPARE POWER CORD SIMER & (ANZ)	72,00
ZBR39720	SPARE PCBA SIMER 6S	52,00
ZBR39770	SPARE LEVEL CONTROL SIMER 6S	31,00
ZBR39790	SPARE TOP COVER SIMER 6S	40,00
ZBR39800	SPARE TOP COVER SIMER 6	40,00
ZBR39820	SPARE SET SEALS SIMER 6/6S	39,00
ZBR44790	SPARE SIMER 4+5 CABLE (UK)	73,00
ZBR48200	SPARE SIMER 4+5 CABLE (ANZ)	72,00
ZBR48260	SPARE SIMER 4+5 IMPELLER	36,00